
lib3mf
Release v2.1.0-beta

3MF Consortium

Aug 27, 2020

CONTENTS

1 API documentation	3
1.1 C++-language bindings	3
1.1.1 Minimal Example Project	4
1.1.2 General Information	6
1.1.3 API-Classes	16
1.2 C-language bindings	53
1.3 Python-language bindings	53
1.4 Pascal-language bindings	53
1.5 C#-language bindings	53
1.6 Golang-language bindings	53
1.7 NodeJS-language bindings	53
2 Obtaining lib3mf	55
3 Using lib3mf	57
4 Meta Information	59
5 Indices and tables	61
Index	63

Welcome! This is the documentation for lib3mf v2.1.0-beta.

lib3mf is an implementation of the 3D Manufacturing Format file standard.

It provides 3MF reading and writing capabilities, as well as conversion and validation tools for input and output data. lib3mf runs on Windows, Linux and MacOS and offers a clean and easy-to-use API in various programming languages to speed up the development and keep integration costs at a minimum.

As 3MF shall become an universal 3D Printing standard, its quick adoption is very important. This library shall lower all barriers of adoption to any possible user, let it be software providers, hardware providers, service providers or middleware tools.

CHAPTER
ONE

API DOCUMENTATION

- *C++*
- *C*
- *Python*
- *Pascal*
- *C#*
- *Golang*
- *NodeJS*

1.1 C++-language bindings

This space describes the usage of lib3mf in a C++ host application.

The C++-language bindings come in two different flavors:

Cpp

If you include the header `Cpp/lib3mf_implicit.hpp`, lib3mf will be loaded dynamically during *load-time* of your host application through your operating system's mechanism for loading libraries.

```
Lib3MF::PWrapper wrapper = CWrapper::loadLibrary();
```

The shared library file `lib3mf.*` needs to reside in a path that your operating systems checks when loading libraries.

CppDynamic

If you include the header `CppDynamic/lib3mf_dynamic.hpp`, Lib3MF will be loaded dynamically during *run-time* of your host application through an explicit call to

Linux

```
Lib3MF::PWrapper wrapper = Lib3MF::CWrapper::loadLibrary("LibraryLocation/lib3mf.so");
```

Mac OSX

```
Lib3MF::PWrapper wrapper = Lib3MF::CWrapper::loadLibrary("LibraryLocation/lib3mf.dylib  
↳");
```

Windows

```
Lib3MF::PWrapper wrapper = Lib3MF::CWrapper::loadLibrary("LibraryLocation/lib3mf.dll  
→");
```

i.e. you need to explicitly provide the location of the shared library file lib3mf.*.

The Lib3MF::PWrapper object provides access to all functionality within lib3mf.

Both flavors of the C++-bindings are header-only which makes it extremly easy to include them into existing projects:

1.1.1 Minimal Example Project

Minimal application code:

Cpp

```
#include <iostream>  
#include "lib3mf_implicit.hpp"  
  
  
int main()  
{  
    try  
    {  
        auto wrapper = Lib3MF::CWrapper::loadLibrary();  
        Lib3MF_uint32 nMajor, nMinor, nMicro;  
        wrapper->GetLibraryVersion(nMajor, nMinor, nMicro);  
        std::cout << "Lib3MF.Version = " << nMajor << "." << nMinor << "." << nMicro;  
        std::string sPreReleaseInfo;  
        if (wrapper->GetPrereleaseInformation(sPreReleaseInfo)) {  
            std::cout << "-" << sPreReleaseInfo;  
        }  
        std::string sBuildInfo;  
        if (wrapper->GetBuildInformation(sBuildInfo)) {  
            std::cout << "+" << sBuildInfo;  
        }  
        std::cout << std::endl;  
    }  
    catch (std::exception &e)  
    {  
        std::cout << e.what() << std::endl;  
        return 1;  
    }  
    return 0;  
}
```

CppDynamic

```
#include <iostream>  
#include "lib3mf_dynamic.hpp"  
  
  
int main()  
{  
    try  
    {  
        std::string libpath = (""); // TODO: put the location of the Lib3MF-library file  
        →here.  
    }
```

(continues on next page)

(continued from previous page)

```

auto wrapper = Lib3MF::CWrapper::loadLibrary(libpath + "/lib3mf."); // TODO: add ↵correct suffix of the library
    Lib3MF_uint32 nMajor, nMinor, nMicro;
    wrapper->GetLibraryVersion(nMajor, nMinor, nMicro);
    std::cout << "Lib3MF.Version = " << nMajor << "." << nMinor << "." << nMicro;
    std::string sPreReleaseInfo;
    if (wrapper->GetPrereleaseInformation(sPreReleaseInfo)) {
        std::cout << "-" << sPreReleaseInfo;
    }
    std::string sBuildInfo;
    if (wrapper->GetBuildInformation(sBuildInfo)) {
        std::cout << "+" << sBuildInfo;
    }
    std::cout << std::endl;
}
catch (std::exception &e)
{
    std::cout << e.what() << std::endl;
    return 1;
}
return 0;
}

```

CMakeLists.txt for minimal project:

Cpp

```

cmake_minimum_required(VERSION 3.5)

set(CMAKE_CURRENT_BINDING_DIR ${CMAKE_CURRENT_SOURCE_DIR}/.)
project(Lib3MFExample_CPPImplicit)
set(CMAKE_CXX_STANDARD 11)
add_executable(Lib3MFExample_CPPImplicit "${CMAKE_CURRENT_SOURCE_DIR}/Lib3MF_example.
    ↵cpp")
find_library(LIB3MFLOCATION lib3mf "${CMAKE_CURRENT_SOURCE_DIR}/../../Implementations/
    ↵*/**/*")
target_link_libraries(Lib3MFExample_CPPImplicit ${LIB3MFLOCATION})
target_include_directories(Lib3MFExample_CPPImplicit PRIVATE "${CMAKE_CURRENT_BINDING_
    ↵DIR}")

```

CppDynamic

```

cmake_minimum_required(VERSION 3.5)

set(CMAKE_CURRENT_BINDING_DIR ${CMAKE_CURRENT_SOURCE_DIR}/.)
project(Lib3MFExample_CPPDynamic)
set(CMAKE_CXX_STANDARD 11)
add_executable(Lib3MFExample_CPPDynamic "${CMAKE_CURRENT_SOURCE_DIR}/Lib3MF_example.
    ↵cpp")
if (UNIX)
    target_link_libraries(Lib3MFExample_CPPDynamic ${CMAKE_DL_LIBS})
endif (UNIX)
target_include_directories(Lib3MFExample_CPPDynamic PRIVATE "${CMAKE_CURRENT_BINDING_
    ↵DIR}")

```

The examples in the Cpp/CppDynamic-folders of the binary SDK follow exactly this pattern.

The remainder of this space is an in-depth API-reference for the functionality of lib3mf.

1.1.2 General Information

The wrapper class CWrapper

```
class Lib3MF::CWrapper
```

All types of the 3MF Library reside in the namespace Lib3MF and all functionality of the 3MF Library resides in Lib3MF::CWrapper.

A suitable way to use Lib3MF::CWrapper is as a singleton.

```
void GetLibraryVersion (Lib3MF_uint32 &nMajor, Lib3MF_uint32 &nMinor, Lib3MF_uint32  
                      &nMicro)
```

retrieves the binary version of this library.

Parameters

- **nMajor** – returns the major version of this library
- **nMinor** – returns the minor version of this library
- **nMicro** – returns the micro version of this library

```
bool GetPrereleaseInformation (std::string &sPrereleaseInfo)
```

retrieves prerelease information of this library.

Returns Does the library provide prerelease version?

Parameters **sPrereleaseInfo** – retrieves prerelease information of this library.

```
bool GetBuildInformation (std::string &sBuildInformation)
```

retrieves build information of this library.

Returns Does the library provide build version?

Parameters **sBuildInformation** – retrieves build information of this library.

```
void GetSpecificationVersion (const std::string &sSpecificationURL, bool &bIsSupported,  
                             Lib3MF_uint32 &nMajor, Lib3MF_uint32 &nMinor,  
                             Lib3MF_uint32 &nMicro)
```

retrieves whether a specification is supported, and if so, which version.

Parameters

- **sSpecificationURL** – URL of extension to check
- **bIsSupported** – returns whether this specification is supported
- **nMajor** – returns the major version of the extension (if IsSupported)
- **nMinor** – returns the minor version of the extension (if IsSupported)
- **nMicro** – returns the micro version of the extension (if IsSupported)

```
PModel CreateModel ()
```

creates an empty model instance.

Returns returns an empty model instance

```
void Release (CBase *pInstance)
```

releases shared ownership of an object instance

Parameters **pInstance** – the object instance to release

```
void Acquire (CBase *pInstance)
```

acquires shared ownership of an object instance

Parameters **pInstance** – the object instance to acquire

```
void SetJournal (const std::string &sJournalPath)
```

Sets the journal file path

Parameters **sJournalPath** – File name of the journal file

```
bool GetLastError (CBase *pInstance, std::string &sLastErrorString)
```

Retrieves the last error string of an instance

Parameters

- **pInstance** – Object where the error occurred.
- **sLastErrorString** – Last Error String

Returns Returns if the instance has a last error.

```
void RetrieveProgressMessage (const eProgressIdentifier eTheProgressIdentifier, std::string &sProgressMessage)
```

Return an English text for a progress identifier.|Note: this is the only function you can call from your callback function.

Parameters

- **eTheProgressIdentifier** – the progress identifier that is passed to the callback function
- **sProgressMessage** – English text for the progress identifier

```
sColor RGBAToColor (const Lib3MF_uint8 nRed, const Lib3MF_uint8 nGreen, const Lib3MF_uint8 nBlue, const Lib3MF_uint8 nAlpha)
```

Creates a Color from uint8 RGBA values

Parameters

- **nRed** – Red value of color (0-255)
- **nGreen** – Green value of color (0-255)
- **nBlue** – Blue value of color (0-255)
- **nAlpha** – Alpha value of color (0-255)

Returns Assembled color

```
sColor FloatRGBAToColor (const Lib3MF_single fRed, const Lib3MF_single fGreen, const Lib3MF_single fBlue, const Lib3MF_single fAlpha)
```

Creates a Color from uint8 RGBA values

Parameters

- **fRed** – Red value of color (0-1)
- **fGreen** – Green value of color (0-1)
- **fBlue** – Blue value of color (0-1)
- **fAlpha** – Alpha value of color (0-1)

Returns Assembled color

```
void ColorToRGBA (const sColor &TheColor, Lib3MF_uint8 &nRed, Lib3MF_uint8 &nGreen, Lib3MF_uint8 &nBlue, Lib3MF_uint8 &nAlpha)
```

Calculates uint8-RGBA-values from a Color

Parameters

- **TheColor** – Color to handle
- **nRed** – Red value of color (0-255)

- **nGreen** – Green value of color (0-255)
- **nBlue** – Blue value of color (0-255)
- **nAlpha** – Alpha value of color (0-255)

```
void ColorToFloatRGBA(const sColor &TheColor, Lib3MF_single &fRed, Lib3MF_single  
                      &fGreen, Lib3MF_single &fBlue, Lib3MF_single &fAlpha)
```

Calculates float-RGBA-values from a Color

Parameters

- **TheColor** – Color to handle
- **fRed** – Red value of color (0-1)
- **fGreen** – Green value of color (0-1)
- **fBlue** – Blue value of color (0-1)
- **fAlpha** – Alpha value of color (0-1)

```
sTransform GetIdentityTransform()
```

Creates an identity transform

Returns Transformation matrix.

```
sTransform GetUniformScaleTransform(const Lib3MF_single fFactor)
```

Creates a uniform scale transform

Parameters **fFactor** – Factor in X, Y and Z

Returns Transformation matrix.

```
sTransform GetScaleTransform(const Lib3MF_single fFactorX, const Lib3MF_single fFac-  
torY, const Lib3MF_single fFactorZ)
```

Creates a scale transform

Parameters

- **fFactorX** – Factor in X
- **fFactorY** – Factor in Y
- **fFactorZ** – Factor in Z

Returns Transformation matrix.

```
sTransform GetTranslationTransform(const Lib3MF_single fVectorX, const Lib3MF_single  
                                  fVectorY, const Lib3MF_single fVectorZ)
```

Creates an translation transform

Parameters

- **fVectorX** – Translation in X
- **fVectorY** – Translation in Y
- **fVectorZ** – Translation in Z

Returns Transformation matrix.

```
typedef std::shared_ptr<CWrapper> Lib3MF::PWrapper
```

Types used in the 3MF Library

Simple types

```
typedef uint8_t Lib3MF_uint8
typedef uint16_t Lib3MF_uint16
typedef uint32_t Lib3MF_uint32
typedef uint64_t Lib3MF_uint64
typedef int8_t Lib3MF_int8
typedef int16_t Lib3MF_int16
typedef int32_t Lib3MF_int32
typedef int64_t Lib3MF_int64
typedef float Lib3MF_single
typedef double Lib3MF_double
using Lib3MF_pvoid = void*
using Lib3MFResult = Lib3MF_int32
```

Enumerations

```
enum class ePropertyType : Lib3MF_int32
{
    enumerator No.PropertyType = 0
    enumerator Base.Material = 1
    enumerator Tex.Coord = 2
    enumerator Colors = 3
    enumerator Composite = 4
    enumerator Multi = 5
}

enum class eSlicesMeshResolution : Lib3MF_int32
{
    enumerator Fullres = 0
    enumerator Lowres = 1
}

enum class eModelUnit : Lib3MF_int32
{
    enumerator MicroMeter = 0
    enumerator MilliMeter = 1
    enumerator CentiMeter = 2
    enumerator Inch = 3
    enumerator Foot = 4
    enumerator Meter = 5
}
```

```
enum class eObjectType : Lib3MF_int32

    enumerator Other = 0
    enumerator Model = 1
    enumerator Support = 2
    enumerator SolidSupport = 3

enum class eTextureType : Lib3MF_int32

    enumerator Unknown = 0
    enumerator PNG = 1
    enumerator JPEG = 2

enum class eTextureTileStyle : Lib3MF_int32

    enumerator Wrap = 0
    enumerator Mirror = 1
    enumerator Clamp = 2
    enumerator NoTileStyle = 3

enum class eTextureFilter : Lib3MF_int32

    enumerator Auto = 0
    enumerator Linear = 1
    enumerator Nearest = 2

enum class eBeamLatticeCapMode : Lib3MF_int32

    enumerator Sphere = 0
    enumerator HemiSphere = 1
    enumerator Butt = 2

enum class eBeamLatticeClipMode : Lib3MF_int32

    enumerator NoClipMode = 0
    enumerator Inside = 1
    enumerator Outside = 2

enum class eBeamLatticeBallMode : Lib3MF_int32

    enumerator None = 0
    enumerator Mixed = 1
    enumerator All = 2

enum class eProgressIdentifier : Lib3MF_int32
```

```
enumerator QUERYCANCELED = 0
enumerator DONE = 1
enumerator CLEANUP = 2
enumerator READSTREAM = 3
enumerator EXTRACTOPCPACKAGE = 4
enumerator READNONROOTMODELS = 5
enumerator READROOTMODEL = 6
enumerator READRESOURCES = 7
enumerator READMESH = 8
enumerator READSLICES = 9
enumerator READBUILD = 10
enumerator READCUSTOMATTACHMENT = 11
enumerator READTEXTUREATTACHMENTS = 12
enumerator CREATEOPCPACKAGE = 13
enumerator WRITEMODELSTOSTREAM = 14
enumerator WRITEROOTMODEL = 15
enumerator WRITENONROOTMODELS = 16
enumerator WRITEATTACHMENTS = 17
enumerator WRITECONTENTTYPES = 18
enumerator WRITENOBJECTS = 19
enumerator WRITENODES = 20
enumerator WRITETRIANGLES = 21
enumerator WRITESLICES = 22
enumerator WRITEKEYSTORE = 23

enum class eBlendMethod : Lib3MF_int32

    enumerator NoBlendMethod = 0
    enumerator Mix = 1
    enumerator Multiply = 2

enum class eEncryptionAlgorithm : Lib3MF_int32

    enumerator AES256_GCM = 1

enum class eWrappingAlgorithm : Lib3MF_int32

    enumerator RSA_OAEP = 0

enum class eMgfAlgorithm : Lib3MF_int32
```

```
enumerator MGF1_SHA1 = 160
enumerator MGF1_SHA224 = 224
enumerator MGF1_SHA256 = 256
enumerator MGF1_SHA384 = 384
enumerator MGF1_SHA512 = 512

enum class eDigestMethod : Lib3MF_int32

    enumerator SHA1 = 160
    enumerator SHA256 = 256

enum class eCompression : Lib3MF_int32

    enumerator NoCompression = 0
    enumerator Deflate = 1
```

Structs

All structs are defined as *packed*, i.e. with the

```
#pragma pack (1)
```

```
struct sTriangle

    Lib3MF_uint32 m_Indices[3]

struct sTriangleProperties

    Lib3MF_uint32 m_ResourceID
    Lib3MF_uint32 m_PropertyIDs[3]

struct sPosition

    Lib3MF_single m_Coordinates[3]

struct sPosition2D

    Lib3MF_single m_Coordinates[2]

struct sCompositeConstituent

    Lib3MF_uint32 m_PropertyID
    Lib3MF_double m_MixingRatio

struct sMultiPropertyLayer

    Lib3MF_uint32 m_ResourceID
    eBlendMethod m_TheBlendMethod
```

```

struct sTex2Coord

    Lib3MF_double m_U
    Lib3MF_double m_V

struct sTransform

    Lib3MF_single m_Fields[4][3]

struct sBox

    Lib3MF_single m_MinCoordinate[3]
    Lib3MF_single m_MaxCoordinate[3]

struct sColor

    Lib3MF_uint8 m_Red
    Lib3MF_uint8 m_Green
    Lib3MF_uint8 m_Blue
    Lib3MF_uint8 m_Alpha

struct sBeam

    Lib3MF_uint32 m_Indices[2]
    Lib3MF_double m_Radii[2]
    eBeamLatticeCapMode m_CapModes[2]

struct sBall

    Lib3MF_uint32 m_Index
    Lib3MF_double m_Radius

```

Function types

```
using ProgressCallback = void (*) (bool*, Lib3MF_double, Lib3MF::eProgressIdentifier,  
                                     Lib3MF_pvoid)
```

A callback function

Returns Returns whether the calculation should be aborted

Parameters

- **dProgressValue** – The value of the progress function: values in the interval [0,1] are progress; < mean no progress update
- **eProgressIdentifier** – An identifier of progress
- **pUserData** – Userdata that is passed to the callback function

```
using WriteCallback = void (*) (Lib3MF_uint64, Lib3MF_uint64, Lib3MF_pvoid)
```

Callback to call for writing a data chunk

Parameters

- **nByteData** – Pointer to the data to be written
- **nNumBytes** – Number of bytes to write
- **pUserData** – Userdata that is passed to the callback function

using ReadCallback = void (*) (Lib3MF_uint64, Lib3MF_uint64, Lib3MF_pvoid)
Callback to call for reading a data chunk

Parameters

- **nByteData** – Pointer to a buffer to read data into
- **nNumBytes** – Number of bytes to read
- **pUserData** – Userdata that is passed to the callback function

using SeekCallback = void (*) (Lib3MF_uint64, Lib3MF_pvoid)
Callback to call for seeking in the stream

Parameters

- **nPosition** – Position in the stream to move to
- **pUserData** – Userdata that is passed to the callback function

using RandomNumberCallback = void (*) (Lib3MF_uint64, Lib3MF_uint64, Lib3MF_pvoid, Lib3MF_uint64*)
Callback to generate random numbers

Parameters

- **nByteData** – Pointer to a buffer to read data into
- **nNumBytes** – Size of available bytes in the buffer
- **pUserData** – Userdata that is passed to the callback function

Returns Number of bytes generated when succeed. 0 or less if failed.

using KeyWrappingCallback = void (*) (Lib3MF_AccessRight, Lib3MF_uint8*, Lib3MF_uint8, Lib3MF_pvoid, Lib3MF_uint64*)**
A callback used to wrap (encrypt) the content key available in keystore resource group

Parameters

- **pKEKParams** – The information about the parameters used used to wrap the key to the contents
- **nInBufferBufferSize** – Buffer to the input value. When encrypting, this should be the plain key. When decrypting, this should be the key cipher.
- **nInBufferBufferSize** – buffer of Buffer to the input value. When encrypting, this should be the plain key. When decrypting, this should be the key cipher.
- **nOutBufferBufferSize** – Number of elements in buffer
- **pOutBufferNeededCount** – will be filled with the count of the written elements, or needed buffer size.
- **pOutBufferBuffer** – buffer of Buffer where the data will be placed. When encrypting, this will be the key cipher. When decrypting, this will be the plain key. When buffer is null, neededBytes contains the required bytes to run.
- **pUserData** – Userdata that is passed to the callback function

Returns The needed/encrypted/decrypted bytes when succeed or zero when error.

```
using ContentEncryptionCallback = void (*) (Lib3MF_ContentEncryptionParams,
                                             Lib3MF_uint8*,      Lib3MF_uint8**,
                                             Lib3MF_pvoid,       Lib3MF_uint64*)
```

A callback to encrypt/decrypt content called on each resource encrypted. This might be called several times depending on content size. If Input is not available(either null or size is 0), clients must return the result of authenticated tag generation/validation.

Parameters

- **pCEKParams** – The params of the encryption process. Client must set/check AuthenticationTag when closing the encryption/decryption process.
- **nInputBufferSize** – Buffer to the original data. In encrypting, this will be the plain data. If decrypting, this will be the cipher data
- **nInputBufferSize** – buffer of Buffer to the original data. In encrypting, this will be the plain data. If decrypting, this will be the cipher data
- **nOutputBufferSize** – Number of elements in buffer
- **pOutputNeededCount** – will be filled with the count of the written elements, or needed buffer size.
- **pOutputBuffer** – buffer of Buffer to hold the transformed data. When encrypting, this will be the cipher data. When decrypting, this shall be the plain data. If buffer is null, neededBytes return the necessary amount of bytes.
- **pUserData** – Userdata that is passed to the callback function

Returns The needed/encrypted/decrypted/verified bytes when succeed or zero when error.

ELib3MFException: The standard exception class of the 3MF Library

Errors in the 3MF Library are reported as Exceptions. It is recommended to not throw these exceptions in your client code.

```
class Lib3MF::ELib3MFException
```

```
void ELib3MFException::what () const noexcept
```

Returns error message

Returns the error message of this exception

```
Lib3MFResult ELib3MFException::getErrorCode () const noexcept
```

Returns error code

Returns the error code of this exception

CInputVector: Adapter for passing arrays as input for functions

Several functions of the 3MF Library expect arrays of integral types or structs as input parameters. To not restrict the interface to, say, std::vector<type>, and to have a more abstract interface than a location in memory and the number of elements to input to a function the 3MF Library provides a templated adapter class to pass arrays as input for functions.

Usually, instances of CInputVector are generated anonymously (or even implicitly) in the call to a function that expects an input array.

```
template<typename T>
```

```
class Lib3MF::CInputVector

    CInputVector(const std::vector<T> &vec)
        Constructs of a CInputVector from a std::vector<T>

    CInputVector(const T *in_data, size_t in_size)
        Constructs of a CInputVector from a memory address and a given number of elements

    const T *CInputVector::data() const
        returns the start address of the data captured by this CInputVector

    size_t CInputVector::size() const
        returns the number of elements captured by this CInputVector
```

1.1.3 API-Classes

CAccessRight

```
class Lib3MF::CAccessRight : public CBase

    PConsumer GetConsumer()
        Gets the consumer associated with this access right

    Returns The consumer instance

    eWrappingAlgorithm GetWrappingAlgorithm()
        Gets the associated encryption algorithm

    Returns The algorithm used for the key in this accessright

    eMgfAlgorithm GetMgfAlgorithm()
        Gets the associated mask generation function algorithm

    Returns The MFG1 algorithm

    eDigestMethod GetDigestMethod()
        Gets the digest method associated

    Returns The digest method for this accessright

typedef std::shared_ptr<CAccessRight> Lib3MF::PAccessRight
Shared pointer to CAccessRight to easily allow reference counting.
```

CAttachment

```
class Lib3MF::CAttachment : public CBase

    std::string GetPath()
        Retrieves an attachment's package path. This function will be removed in a later release.

    Returns returns the attachment's package path string

    void SetPath(const std::string &sPath)
        Sets an attachment's package path. This function will be removed in a later release.

    Parameters sPath – new path of the attachment.
```

PPackagePart **PackagePart** ()

Returns the PackagePart that is this attachment.

Returns The PackagePart of this attachment.

std::string GetRelationshipType ()

Retrieves an attachment's relationship type

Returns returns the attachment's package relationship type string

void SetRelationshipType (const std::string &sPath)

Sets an attachment's relationship type.

Parameters **sPath** – new relationship type string.

void WriteToFile (const std::string &sFileName)

Writes out the attachment as file.

Parameters **sFileName** – file to write into.

void ReadFromFile (const std::string &sFileName)

Reads an attachment from a file.

Parameters **sFileName** – file to read from.

Lib3MF_uint64 GetStreamSize ()

Retrieves the size of the attachment stream

Returns the stream size

void WriteToBuffer (std::vector<Lib3MF_uint8> &BufferBuffer)

Writes out the attachment into a buffer

Parameters **BufferBuffer** – Buffer to write into

void ReadFromBuffer (const CInputVector<Lib3MF_uint8> &BufferBuffer)

Reads an attachment from a memory buffer

Parameters **BufferBuffer** – Buffer to read from

typedef std::shared_ptr<CAttachment> Lib3MF::PAttachment

Shared pointer to CAttachment to easily allow reference counting.

CBase**class Lib3MF::CBase****typedef std::shared_ptr<CBase> Lib3MF::PBase**

Shared pointer to CBase to easily allow reference counting.

CBaseMaterialGroup**class Lib3MF::CBaseMaterialGroup : public CResource**

The BaseMaterialGroup corresponds to a basematerials-element within a 3MF document

Lib3MF_uint32 GetCount ()

Retrieves the count of base materials in the material group.

Returns returns the count of base materials.

void GetAllPropertyIDs (std::vector<Lib3MF_uint32> &PropertyIDsBuffer)

returns all the PropertyIDs of all materials in this group

Parameters **PropertyIDsBuffer** – PropertyID of the material in the material group.

Lib3MF_uint32 AddMaterial (const std::string &sName, const sColor &DisplayColor)

Adds a new material to the material group

Parameters

- **sName** – new name of the base material.

- **DisplayColor** – Display color of the material

Returns returns new PropertyID of the new material in the material group.

void RemoveMaterial (const Lib3MF_uint32 nPropertyID)

Removes a material from the material group.

Parameters **nPropertyID** – PropertyID of the material in the material group.

std::string GetName (const Lib3MF_uint32 nPropertyID)

Returns the base material's name

Parameters **nPropertyID** – PropertyID of the material in the material group.

Returns returns the name of the base material.

void SetName (const Lib3MF_uint32 nPropertyID, const std::string &sName)

Sets a base material's name

Parameters

- **nPropertyID** – PropertyID of the material in the material group.

- **sName** – new name of the base material.

void SetDisplayColor (const Lib3MF_uint32 nPropertyID, const sColor &TheColor)

Sets a base material's display color.

Parameters

- **nPropertyID** – PropertyID of the material in the material group.

- **TheColor** – The base material's display color

sColor GetDisplayColor (const Lib3MF_uint32 nPropertyID)

Returns a base material's display color.

Parameters **nPropertyID** – PropertyID of the material in the material group.

Returns The base material's display color

typedef std::shared_ptr<CBaseMaterialGroup> Lib3MF::PBaseMaterialGroup

Shared pointer to CBaseMaterialGroup to easily allow reference counting.

CBaseMaterialGroupIterator

class Lib3MF::CBaseMaterialGroupIterator : public CResourceIterator

PBaseMaterialGroup GetCurrentBaseMaterialGroup ()

Returns the MaterialGroup the iterator points at.

Returns returns the BaseMaterialGroup instance.

typedef std::shared_ptr<CBaseMaterialGroupIterator> Lib3MF::PBaseMaterialGroupIterator

Shared pointer to CBaseMaterialGroupIterator to easily allow reference counting.

CBeamLattice

```
class Lib3MF::CBeamLattice : public CBase
```

Lib3MF_double GetMinLength()
Returns minimal length of beams for the beamlattice.
Parameters **dMinLength** – minimal length of beams for the beamlattice

```
void SetMinLength(const Lib3MF_double dMinLength)  

Sets the minimal length of beams for the beamlattice.
```

Parameters **dMinLength** – minimal length of beams for the beamlattice

```
void GetClipping(eBeamLatticeClipMode &eClipMode, Lib3MF_uint32 &nUniqueRe-  

sourceID)  

Returns the clipping mode and the clipping-mesh for the beamlattice of this mesh.
```

Parameters

- **eClipMode** – contains the clip mode of this mesh
- **nUniqueResourceID** – filled with the UniqueResourceID of the clipping mesh-object or an undefined value if pClipMode is MODELBEAMLATTICE-CLIPMODE_NONE

```
void SetClipping(const eBeamLatticeClipMode eClipMode, const Lib3MF_uint32  

nUniqueResourceID)  

Sets the clipping mode and the clipping-mesh for the beamlattice of this mesh.
```

Parameters

- **eClipMode** – contains the clip mode of this mesh
- **nUniqueResourceID** – the UniqueResourceID of the clipping mesh-object. This mesh-object has to be defined before setting the Clipping.

```
bool GetRepresentation(Lib3MF_uint32 &nUniqueResourceID)  

Returns the representation-mesh for the beamlattice of this mesh.
```

Returns flag whether the beamlattice has a representation mesh.

```
Parameters nUniqueResourceID – filled with the UniqueResourceID of the clipping mesh-object.
```

```
void SetRepresentation(const Lib3MF_uint32 nUniqueResourceID)  

Sets the representation-mesh for the beamlattice of this mesh.
```

Parameters **nUniqueResourceID** – the UniqueResourceID of the representation mesh-object. This mesh-object has to be defined before setting the representation.

```
void GetBallOptions(eBeamLatticeBallMode &eBallMode, Lib3MF_double &dBallRadius)  

Returns the ball mode and the default ball radius for the beamlattice of this mesh. Returns  

the ball mode and the default ball radius for the beamlattice of this mesh.
```

param **eBallMode** contains the ball mode of this mesh

param **dBallRadius** default ball radius of balls for the beamlattice

```
typedef std::shared_ptr<CBeamLattice> Lib3MF::PBeamLattice
```

Shared pointer to CBeamLattice to easily allow reference counting.

CBeamSet

```
class Lib3MF::CBeamSet : public CBase

void SetName (const std::string &sName)
    Sets a beamset's name string

    Parameters sName – new name of the beamset.

std::string GetName ()
    Retrieves a beamset's name string

    Returns returns the name of the beamset.

void SetIdentifier (const std::string &sIdentifier)
    Sets a beamset's identifier string

    Parameters sIdentifier – new name of the beamset.

std::string GetIdentifier ()
    Retrieves a beamset's identifier string

    Returns returns the identifier of the beamset.

Lib3MF_uint32 GetReferenceCount ()
    Retrieves the reference count of a beamset

    Returns returns the reference count

void SetReferences (const CInputVector<Lib3MF_uint32> &ReferencesBuffer)
    Sets the references of a beamset

    Parameters ReferencesBuffer – the new indices of all beams in this beamset

void GetReferences (std::vector<Lib3MF_uint32> &ReferencesBuffer)
    Retrieves the references of a beamset

    Parameters ReferencesBuffer – retrieves the indices of all beams in this beamset

Lib3MF_uint32 GetBallReferenceCount ()
    Retrieves the ball reference count of a beamset

    Returns returns the ball reference count

void SetBallReferences (const CInputVector<Lib3MF_uint32> &BallReferencesBuffer)
    Sets the ball references of a beamset

    Parameters BallReferencesBuffer – the new indices of all balls in this beamset

void GetBallReferences (std::vector<Lib3MF_uint32> &BallReferencesBuffer)
    Retrieves the ball references of a beamset

    Parameters BallReferencesBuffer – retrieves the indices of all balls in this beamset

typedef std::shared_ptr<CBeamSet> Lib3MF::PBeamSet
    Shared pointer to CBeamSet to easily allow reference counting.
```

CBuildItem

```
class Lib3MF::CBuildItem : public CBase
```

PObject **GetObjectResource**()
 Retrieves the object resource associated to a build item
Returns returns the associated resource instance

std::string GetUUID(bool &*bHasUUID*)
 returns, whether a build item has a UUID and, if true, the build item's UUID
Parameters *bHasUUID* – flag whether the build item has a UUID
Returns the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxxxx’

void SetUUID(**const** std::string &*sUUID*)
 sets the build item's UUID
Parameters *sUUID* – the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxxxx’

Lib3MF_uint32 GetObjectResourceID()
 Retrieves the object UniqueResourceID associated to a build item
Returns returns the UniqueResourceID of the object

bool HasObjectTransform()
 Checks, if a build item has a non-identity transformation matrix
Returns returns true, if the transformation matrix is not the identity

sTransform **GetObjectTransform**()
 Retrieves a build item's transformation matrix.
Returns returns the transformation matrix

void SetObjectTransform(**const** *sTransform* &*Transform*)
 Sets a build item's transformation matrix.
Parameters *Transform* – new transformation matrix

std::string GetPartNumber()
 Retrieves a build item's part number string
Returns Returns a build item's part number string

void SetPartNumber(**const** std::string &*sSetPartnumber*)
 Sets a build item's part number string
Parameters *sSetPartnumber* – new part number string for referencing parts from the outside world

PMetaDataGroup **GetMetaDataGroup**()
 Returns the metadatagroup of this build item
Returns returns an Instance of the metadatagroup of this build item

sBox **GetOutbox**()
 Returns the outbox of a build item
Returns Outbox of this build item

typedef std::shared_ptr<*CBuildItem*> Lib3MF::PBuildItem
 Shared pointer to CBuildItem to easily allow reference counting.

CBuildItemIterator

```
class Lib3MF::CBuildItemIterator : public CBase
```

bool MoveNext ()

Iterates to the next build item in the list.

Returns Iterates to the next build item in the list.

bool MovePrevious ()

Iterates to the previous build item in the list.

Returns Iterates to the previous build item in the list.

PBuildItem GetCurrent ()

Returns the build item the iterator points at.

Returns returns the build item instance.

PBuildItemIterator Clone ()

Creates a new build item iterator with the same build item list.

Returns returns the cloned Iterator instance

Lib3MF_uint64 Count ()

Returns the number of build items the iterator captures.

Returns returns the number of build items the iterator captures.

typedef std::shared_ptr<CBuildItemIterator> Lib3MF::PBuildItemIterator

Shared pointer to CBuildItemIterator to easily allow reference counting.

CColorGroup

```
class Lib3MF::CColorGroup : public CResource
```

Lib3MF_uint32 GetCount ()

Retrieves the count of base materials in this Color Group.

Returns returns the count of colors within this color group.

void GetAllPropertyIDs (std::vector<Lib3MF_uint32> &PropertyIDsBuffer)

returns all the PropertyIDs of all colors within this group

Parameters **PropertyIDsBuffer** – PropertyID of the color in the color group.

Lib3MF_uint32 AddColor (const sColor &TheColor)

Adds a new value.

Parameters **TheColor** – The new color

Returns PropertyID of the new color within this color group.

void RemoveColor (const Lib3MF_uint32 nPropertyID)

Removes a color from the color group.

Parameters **nPropertyID** – PropertyID of the color to be removed from the color group.

void SetColor (const Lib3MF_uint32 nPropertyID, const sColor &TheColor)

Sets a color value.

Parameters

- **nPropertyID** – PropertyID of a color within this color group.
- **TheColor** – The color

sColor **GetColor** (**const Lib3MF_uint32 nPropertyID**)
Sets a color value.

Parameters **nPropertyID** – PropertyID of a color within this color group.
Returns The color

typedef std::shared_ptr<*CColorGroup*> **Lib3MF::PColorGroup**
Shared pointer to CColorGroup to easily allow reference counting.

CColorGroupIterator

class Lib3MF::CColorGroupIterator : public *CResourceIterator*

PColorGroup **GetCurrentColorGroup** ()
Returns the ColorGroup the iterator points at.

Returns returns the ColorGroup instance.

typedef std::shared_ptr<*CColorGroupIterator*> **Lib3MF::PColorGroupIterator**
Shared pointer to CColorGroupIterator to easily allow reference counting.

CComponent

class Lib3MF::CComponent : public *CBase*

PObject **GetObjectResource** ()
Returns the Resource Instance of the component.

Returns filled with the Resource Instance.

Lib3MF_uint32 **GetObjectResourceID** ()
Returns the UniqueResourceID of the component.

Returns returns the UniqueResourceID.

std::string **GetUUID** (bool &*bHasUUID*)
returns, whether a component has a UUID and, if true, the component's UUID

Parameters **bHasUUID** – flag whether the component has a UUID

Returns the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxx’

void **SetUUID** (**const std::string &sUUID**)
sets the component's UUID

Parameters **sUUID** – the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxx’

bool **HasTransform** ()
Returns, if the component has a different transformation than the identity matrix

Returns if true is returned, the transformation is not equal than the identity

sTransform **GetTransform** ()
Returns the transformation matrix of the component.

Returns filled with the component transformation matrix

void SetTransform (const *sTransform* &*Transform*)

Sets the transformation matrix of the component.

Parameters *Transform* – new transformation matrix

typedef std::shared_ptr<CComponent> Lib3MF::PComponent

Shared pointer to CComponent to easily allow reference counting.

CComponentsObject

class Lib3MF::CComponentsObject : public CObject

PComponent AddComponent (CObject **pObjectResource*, const *sTransform* &*Transform*)

Adds a new component to a components object.

Parameters

- **pObjectResource** – object to add as component. Must not lead to circular references!
- **Transform** – optional transform matrix for the component.

Returns new component instance

PComponent GetComponent (const Lib3MF_uint32 *nIndex*)

Retrieves a component from a component object.

Parameters *nIndex* – index of the component to retrieve (0 to componentcount - 1)

Returns component instance

Lib3MF_uint32 GetComponentCount ()

Retrieves a component count of a component object.

Returns returns the component count

typedef std::shared_ptr<CComponentsObject> Lib3MF::PComponentsObject

Shared pointer to CComponentsObject to easily allow reference counting.

CComponentsObjectIterator

class Lib3MF::CComponentsObjectIterator : public CResourceIterator

PComponentsObject GetCurrentComponentsObject ()

Returns the ComponentsObject the iterator points at.

Returns returns the ComponentsObject instance.

typedef std::shared_ptr<CComponentsObjectIterator> Lib3MF::PComponentsObjectIterator

Shared pointer to CComponentsObjectIterator to easily allow reference counting.

CCompositeMaterials

```
class Lib3MF::CCompositeMaterials : public CResource
```

Lib3MF_uint32 GetCount ()

Retrieves the count of Composite-s in the CompositeMaterials.

Returns returns the count of Composite-s

void GetAllPropertyIDs (std::vector<*Lib3MF_uint32*> &PropertyIDsBuffer)

returns all the PropertyIDs of all Composite-Mixing Values in this CompositeMaterials

Parameters **PropertyIDsBuffer** – PropertyID of the Composite-Mixing Values in the CompositeMaterials.

PBaseMaterialGroup GetBaseMaterialGroup ()

Obtains the BaseMaterialGroup instance of this CompositeMaterials.

Returns returns the BaseMaterialGroup instance of this CompositeMaterials

*Lib3MF_uint32 AddComposite (const CInputVector<*sCompositeConstituent*> &CompositeBuffer)*

Adds a new Composite-Mixing Values to the CompositeMaterials.

Parameters **CompositeBuffer** – The Composite Constituents to be added as composite

Returns returns new PropertyID of the new Composite in the CompositeMaterials.

void RemoveComposite (const *Lib3MF_uint32* nPropertyID)

Removes a Composite-Maxing Ratio from the CompositeMaterials.

Parameters **nPropertyID** – PropertyID of the Composite-Mixing Values in the CompositeMaterials to be removed.

void GetComposite (const *Lib3MF_uint32* nPropertyID, std::vector<*sCompositeConstituent*> &CompositeBuffer)

Obtains a Composite-Maxing Ratio of this CompositeMaterials.

Parameters

- **nPropertyID** – the PropertyID of the Composite-Maxing Ratio in the CompositeMaterials.
- **CompositeBuffer** – The Composite-Mixing Values with the given PropertyID

typedef std::shared_ptr<*CCompositeMaterials*> Lib3MF::PCompositeMaterials

Shared pointer to CCompositeMaterials to easily allow reference counting.

CCompositeMaterialsIterator

```
class Lib3MF::CCompositeMaterialsIterator : public CResourceIterator
```

PCompositeMaterials GetCurrentCompositeMaterials ()

Returns the CompositeMaterials the iterator points at.

Returns returns the CompositeMaterials instance.

typedef std::shared_ptr<*CCompositeMaterialsIterator*> Lib3MF::PCompositeMaterialsIterator

Shared pointer to CCompositeMaterialsIterator to easily allow reference counting.

CConsumer

```
class Lib3MF::CConsumer : public CBase

    std::string GetConsumerID()
        Gets the consumerid

        Returns A unique identifier for the consumers

    std::string GetKeyID()
        Gets the keyid

        Returns The identifier for the key of this consumer

    std::string GetKeyValue()
        Gets the keyvalue associated with this consumer

        Returns The public key, when available, of this consumer

typedef std::shared_ptr<CConsumer> Lib3MF::PConsumer
Shared pointer to CConsumer to easily allow reference counting.
```

CContentEncryptionParams

```
class Lib3MF::CContentEncryptionParams : public CBase

    eEncryptionAlgorithm GetEncryptionAlgorithm()
        Returns the encryption method to be used in this encryption process

        Returns

    void GetKey(std::vector<Lib3MF_uint8> &ByteDataBuffer)
        Gets the key for the resource associated

            Parameters ByteDataBuffer – Pointer to a buffer where to place the key.

    void GetInitializationVector(std::vector<Lib3MF_uint8> &ByteDataBuffer)
        Gets the IV data

            Parameters ByteDataBuffer – Pointer to a buffer where to place the data.

    void GetAuthenticationTag(std::vector<Lib3MF_uint8> &ByteDataBuffer)
        A handler descriptor that uniquely identifies the context of the resource. Each resource will be assigned a different value

            Parameters ByteDataBuffer – Pointer to a buffer where to place the data.

    void SetAuthenticationTag(const CInputVector<Lib3MF_uint8> &ByteDataBuffer)
        Sets the authentication tag

            Parameters ByteDataBuffer – The authentication tag size

    void GetAdditionalAuthenticationData(std::vector<Lib3MF_uint8> &ByteDataBuffer)
        A handler descriptor that uniquely identifies the context of the resource. Each resource will be assigned a different value

            Parameters ByteDataBuffer – Buffer where the data will be placed

    Lib3MF_uint64 GetDescriptor()
        A handler descriptor that uniquely identifies the context of the resource. Each resource will be assigned a different value
```

Returns

```
std::string GetKeyUUID()
```

Gets the resourcedatagroup keyuuid

Returns The resourcedatagroup keyuuid that may be used to reference an external key

```
typedef std::shared_ptr<CContentEncryptionParams> Lib3MF::PContentEncryptionParams
```

Shared pointer to CContentEncryptionParams to easily allow reference counting.

CKeyStore

```
class Lib3MF::CKeyStore : public CBase
```

```
PConsumer AddConsumer (const std::string &sConsumerID, const std::string &sKeyID, const
std::string &sKeyValue)
```

Adds a consumer to the keystore

Parameters

- **sConsumerID** – A unique identifier for the consumer
- **sKeyID** – The id of the key of the consumer
- **sKeyValue** – The public key for this consumer in PEM format

Returns The consumer instance

```
Lib3MF_uint64 GetConsumerCount()
```

Gets the number of consumers in the keystore

Returns The consumer count

```
PConsumer GetConsumer (const Lib3MF_uint64 nConsumerIndex)
```

Get a consumer from the keystore

Parameters **nConsumerIndex** – The index of the consumer

Returns The consumer instance

```
void RemoveConsumer (CConsumer *pConsumer)
```

Removes a consumer from the keystore

Parameters **pConsumer** – The consumer instance to remove

```
PConsumer FindConsumer (const std::string &sConsumerID)
```

Finds a consumer by ID

Parameters **sConsumerID** – The ID of the consumer

Returns The consumer instance

```
Lib3MF_uint64 GetResourceDataGroupCount()
```

Gets the number of resource data group in the keystore

Returns The number of resource data available

```
PResourceDataGroup AddResourceDataGroup()
```

Adds a resource data group into the keystore.

Returns The resource data group instance

```
PResourceDataGroup GetResourceDataGroup (const Lib3MF_uint64 nResourceDataIndex)
```

Gets a resource data group

Parameters `nResourceDataIndex` – The index of the resource data

Returns The resource data group instance

`void RemoveResourceDataGroup (CResourceDataGroup *pResourceDataGroup)`

Removes a resource data group

Parameters `pResourceDataGroup` – The resource data group instance

`PResourceDataGroup FindResourceDataGroup (CPackagePart *pPartPath)`

Finds a resource data group that contains a particular resourcedata

Parameters `pPartPath` – The target path for the resourcedata hold by the resource data group

Returns The data resource instance

`PResourceData AddResourceData (CResourceDataGroup *pResourceDataGroup, CPackagePart *pPartPath, const eEncryptionAlgorithm eAlgorithm, const eCompression eCompression, const CInputVector<Lib3MF_uint8> &AdditionalAuthenticationDataBuffer)`

Add resourcedata to resourcedatagroup element

Parameters

- `pResourceDataGroup` – The resource data group where to add this resource data
- `pPartPath` – The path of the part to be encrypted
- `eAlgorithm` – The encryption algorithm to be used to encrypt this resource
- `eCompression` – Whether compression should be used prior to encryption
- `AdditionalAuthenticationDataBuffer` – Additional data to be encrypted along the contents for better security

Returns The data resource instance

`void RemoveResourceData (CResourceData *pResourceData)`

Removes a resource data

Parameters `pResourceData` – The resource data to be removed

`PResourceData FindResourceData (CPackagePart *pResourcePath)`

Finds a resource data on this resource group

Parameters `pResourcePath` – The target path for the resourcedata

Returns The resource data instance

`Lib3MF_uint64 GetResourceDataCount ()`

Gets the number of resource data in the keysore

Returns The number of resource data available

`PResourceData GetResourceData (const Lib3MF_uint64 nResourceDataIndex)`

Gets a resource data

Parameters `nResourceDataIndex` – The index of the resource data

Returns The data resource instance

`std::string GetUUID (bool &bHasUUID)`

Gets the keystore UUID

Parameters `bHasUUID` – flag whether the keystore has a UUID

Returns returns the keystore uuid.

```
void SetUUID (const std::string &sUUID)
    Sets the keystore UUID

Parameters sUUID – The new keystore uuid.
```

```
typedef std::shared_ptr<CKeyStore> Lib3MF::PKeyStore
    Shared pointer to CKeyStore to easily allow reference counting.
```

CMeshObject

```
class Lib3MF::CMeshObject : public CObject
```

```
Lib3MF_uint32 GetVertexCount ()
    Returns the vertex count of a mesh object.
```

Returns filled with the vertex count.

```
Lib3MF_uint32 GetTriangleCount ()
    Returns the triangle count of a mesh object.
```

Returns filled with the triangle count.

```
sPosition GetVertex (const Lib3MF_uint32 nIndex)
    Returns the vertex count of a mesh object.
```

Parameters nIndex – Index of the vertex (0 to vertexcount - 1)

Returns filled with the vertex coordinates.

```
void SetVertex (const Lib3MF_uint32 nIndex, const sPosition &Coordinates)
    Sets the coordinates of a single vertex of a mesh object
```

Parameters

- nIndex – Index of the vertex (0 to vertexcount - 1)
- Coordinates – contains the vertex coordinates.

```
Lib3MF_uint32 AddVertex (const sPosition &Coordinates)
    Adds a single vertex to a mesh object
```

Parameters Coordinates – contains the vertex coordinates.

Returns Index of the new vertex

```
void GetVertices (std::vector<sPosition> &VerticesBuffer)
    Obtains all vertex positions of a mesh object
```

Parameters VerticesBuffer – contains the vertex coordinates.

```
Triangle GetTriangle (const Lib3MF_uint32 nIndex)
    Returns indices of a single triangle of a mesh object.
```

Parameters nIndex – Index of the triangle (0 to trianglecount - 1)

Returns filled with the triangle indices.

```
void SetTriangle (const Lib3MF_uint32 nIndex, const sTriangle &Indices)
    Sets the indices of a single triangle of a mesh object.
```

Parameters

- nIndex – Index of the triangle (0 to trianglecount - 1)
- Indices – contains the triangle indices.

`Lib3MF_uint32 AddTriangle (const sTriangle &Indices)`

Adds a single triangle to a mesh object

Parameters **Indices** – contains the triangle indices.

Returns Index of the new triangle

`void GetTriangleIndices (std::vector<sTriangle> &IndicesBuffer)`

Get all triangles of a mesh object

Parameters **IndicesBuffer** – contains the triangle indices.

`void SetObjectLevelProperty (const Lib3MF_uint32 nUniqueResourceID, const Lib3MF_uint32 nPropertyID)`

Sets the property at the object-level of the mesh object.

Parameters

- **nUniqueResourceID** – the object-level Property UniqueResourceID.
- **nPropertyID** – the object-level PropertyID.

`bool GetObjectLevelProperty (Lib3MF_uint32 &nUniqueResourceID, Lib3MF_uint32 &nPropertyID)`

Gets the property at the object-level of the mesh object.

Parameters

- **nUniqueResourceID** – the object-level Property UniqueResourceID.
- **nPropertyID** – the object-level PropertyID.

Returns Has an object-level property been specified?

`void SetTriangleProperties (const Lib3MF_uint32 nIndex, const sTriangleProperties &Properties)`

Sets the properties of a single triangle of a mesh object.

Parameters

- **nIndex** – Index of the triangle (0 to trianglecount - 1)
- **Properties** – contains the triangle properties.

`void GetTriangleProperties (const Lib3MF_uint32 nIndex, sTriangleProperties &Property)`

Gets the properties of a single triangle of a mesh object.

Parameters

- **nIndex** – Index of the triangle (0 to trianglecount - 1)
- **Property** – returns the triangle properties.

`void SetAllTriangleProperties (const CInputVector<sTriangleProperties> &PropertiesArrayBuffer)`

Sets the properties of all triangles of a mesh object. Sets the object level property to the first entry of the passed triangle properties, if not yet specified.

Parameters **PropertiesArrayBuffer** – contains the triangle properties array. Must have trianglecount elements.

`void GetAllTriangleProperties (std::vector<sTriangleProperties> &Properties ArrayBuffer)`

Gets the properties of all triangles of a mesh object.

Parameters **PropertiesArrayBuffer** – returns the triangle properties array. Must have trianglecount elements.

```
void ClearAllProperties()
```

Clears all properties of this mesh object (triangle and object-level).

```
void SetGeometry(const CInputVector<sPosition> &VerticesBuffer, const CInputVec-  
tor<sTriangle> &IndicesBuffer)
```

Set all triangles of a mesh object

Parameters

- **VerticesBuffer** – contains the positions.

- **IndicesBuffer** – contains the triangle indices.

```
bool IsManifoldAndOriented()
```

Retrieves, if an object describes a topologically oriented and manifold mesh, according to the core spec.

Returns returns, if the object is oriented and manifold.

```
PBeamLattice BeamLattice()
```

Retrieves the BeamLattice within this MeshObject.

Returns the BeamLattice within this MeshObject

```
typedef std::shared_ptr<CMeshObject> Lib3MF::PMeshObject
```

Shared pointer to CMeshObject to easily allow reference counting.

CMeshObjectIterator

```
class Lib3MF::CMeshObjectIterator : public CResourceIterator
```

```
PMeshObject GetCurrentMeshObject()
```

Returns the MeshObject the iterator points at.

Returns returns the MeshObject instance.

```
typedef std::shared_ptr<CMeshObjectIterator> Lib3MF::PMeshObjectIterator
```

Shared pointer to CMeshObjectIterator to easily allow reference counting.

CMetaData

```
class Lib3MF::CMetaData : public CBase
```

```
std::string GetNameSpace()
```

returns the namespace URL of the metadata

Returns the namespace URL of the metadata

```
void SetNameSpace(const std::string &sNameSpace)
```

sets a new namespace URL of the metadata

Parameters **sNameSpace** – the new namespace URL of the metadata

```
std::string GetName()
```

returns the name of a metadata

Returns the name of the metadata

```
void SetName(const std::string &sName)
```

sets a new name of a metadata

Parameters **sName** – the new name of the metadata

```
std::string GetKey ()
    returns the (namespace+name) of a metadata

Returns the key (namespace+name) of the metadata

bool GetMustPreserve ()
    returns, whether a metadata must be preserved

Returns returns, whether a metadata must be preserved

void SetMustPreserve (const bool bMustPreserve)
    sets whether a metadata must be preserved

Parameters bMustPreserve – a new value whether a metadata must be preserved

std::string GetType ()
    returns the type of a metadata

Returns the type of the metadata

void SetType (const std::string &sType)
    sets a new type of a metadata. This must be a simple XML type

Parameters sType – a new type of the metadata

std::string GetValue ()
    returns the value of the metadata

Returns the value of the metadata

void SetValue (const std::string &sValue)
    sets a new value of the metadata

Parameters sValue – a new value of the metadata

typedef std::shared_ptr<CMetaData> Lib3MF::PMetaData
Shared pointer to CMetaData to easily allow reference counting.
```

CMetaDataGroup

```
class Lib3MF::CMetaDataGroup : public CBase

Lib3MF_uint32 GetMetaDataCount ()
    returns the number of metadata in this metadatagroup

Returns returns the number metadata

PMetaData GetMetaData (const Lib3MF_uint32 nIndex)
    returns a metadata value within this metadatagroup

Parameters nIndex – Index of the Metadata.

Returns an instance of the metadata

PMetaData GetMetaDataByKey (const std::string &sNameSpace, const std::string &sName)
    returns a metadata value within this metadatagroup

Parameters

- sNameSpace – the namespace of the metadata
- sName – the name of the Metadata

Returns an instance of the metadata
```

```
void RemoveMetaDataTableByIndex (const Lib3MF_uint32 nIndex)
    removes metadata by index from the model.
```

Parameters **nIndex** – Index of the metadata to remove

```
void RemoveMetaDataTable (CMetaData *pTheMetaDataTable)
    removes metadata from the model.
```

Parameters **pTheMetaDataTable** – The metadata to remove

```
PMetaData AddMetaDataTable (const std::string &sNameSpace, const std::string &sName, const
                           std::string &sValue, const std::string &sType, const bool bMustPreserve)
    adds a new metadata to this metadatagroup
```

Parameters

- **sNameSpace** – the namespace of the metadata
- **sName** – the name of the metadata
- **sValue** – the value of the metadata
- **sType** – the type of the metadata
- **bMustPreserve** – shuold the metadata be preserved

Returns a new instance of the metadata

```
typedef std::shared_ptr<CMetaDataGroup> Lib3MF::PMetaDataGroup
    Shared pointer to CMetaDataGroup to easily allow reference counting.
```

CModel

```
class Lib3MF::CModel : public CBase
```

```
PPackagePart RootModelPart ()
```

Returns the PackagePart within the OPC package that holds the root model.

Returns the PackagePart within the OPC package that holds the model-file

```
PPackagePart FindOrCreatePackagePart (const std::string &sAbsolutePath)
```

Returns a new PackagePart for use within the OPC package.

Parameters **sAbsolutePath** – the absolute Path (physical location) within the OPC package

Returns the new PackagePart within the OPC package

```
void SetUnit (const eModelUnit eUnit)
```

sets the units of a model.

Parameters **eUnit** – Unit enum value for the model unit

```
eModelUnit GetUnit ()
```

returns the units of a model.

Returns Unit enum value for the model unit

```
std::string GetLanguage ()
```

retrieves the language of a model

Returns language identifier

void **SetLanguage** (**const** std::string &*sLanguage*)
sets the language of a model

Parameters **sLanguage** – language identifier

PWriter **QueryWriter** (**const** std::string &*sWriterClass*)
creates a model writer instance for a specific file type

Parameters **sWriterClass** – string identifier for the file type

Returns string identifier for the file type

PReader **QueryReader** (**const** std::string &*sReaderClass*)
creates a model reader instance for a specific file type

Parameters **sReaderClass** – string identifier for the file type

Returns string identifier for the file type

PTexture2D **GetTexture2DByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a model texture by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the texture2d instance

ePropertyType **GetPropertyTypeByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
returns a Property's type

Parameters **nUniqueResourceID** – Resource ID of the Property to Query

Returns returns a Property's type

PBaseMaterialGroup **GetBaseMaterialGroupByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a model base material group by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the BaseMaterialGroup instance

PTexture2DGroup **GetTexture2DGroupByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a model texture2d group by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the Texture2DGroup instance

PCompositeMaterials **GetCompositeMaterialsByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a model CompositeMaterials by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the CompositeMaterials instance

PMultiPropertyGroup **GetMultiPropertyGroupByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a model MultiPropertyGroup by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the MultiPropertyGroup instance

PMeshObject **GetMeshObjectByID** (**const** Lib3MF_uint32 *nUniqueResourceID*)
finds a mesh object by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the mesh object instance

PComponentsObject **GetComponentsObjectByID** (**const Lib3MF_uint32 nUniqueResourceID**)
finds a components object by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the components object instance

PColorGroup **GetColorGroupByID** (**const Lib3MF_uint32 nUniqueResourceID**)
finds a model color group by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the ColorGroup instance

PSliceStack **GetSliceStackByID** (**const Lib3MF_uint32 nUniqueResourceID**)
finds a model slicestack by its UniqueResourceID

Parameters **nUniqueResourceID** – UniqueResourceID

Returns returns the slicestack instance

`std::string GetBuildUUID (bool &bHasUUID)`
returns, whether a build has a UUID and, if true, the build's UUID

Parameters **bHasUUID** – flag whether the build has a UUID

Returns the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxx’

`void SetBuildUUID (const std::string &sUUID)`
sets the build's UUID

Parameters **sUUID** – the UUID as string of the form ‘xxxxxxxx-xxxx-xxxx-xxxxxxxxxxxx’

PBuildItemIterator **GetBuildItems** ()
creates a build item iterator instance with all build items.

Returns returns the iterator instance.

Box **GetOutbox** ()
Returns the outbox of a Model

Returns Outbox of this Model

PResourceIterator **GetResources** ()
creates a resource iterator instance with all resources.

Returns returns the iterator instance.

PObjectIterator **GetObjects** ()
creates a resource iterator instance with all object resources.

Returns returns the iterator instance.

PMeshObjectIterator **GetMeshObjects** ()
creates a resource iterator instance with all mesh object resources.

Returns returns the iterator instance.

PComponentsObjectIterator **GetComponentsObjects** ()
creates a resource iterator instance with all components object resources.

Returns returns the iterator instance.

PTexture2DIterator **GetTexture2Ds ()**
creates a Texture2DIterator instance with all texture2d resources.

Returns returns the iterator instance.

PBaseMaterialGroupIterator **GetBaseMaterialGroups ()**
creates a BaseMaterialGroupIterator instance with all base material resources.

Returns returns the iterator instance.

PColorGroupIterator **GetColorGroups ()**
creates a ColorGroupIterator instance with all ColorGroup resources.

Returns returns the iterator instance.

PTexture2DGroupIterator **GetTexture2DGroups ()**
creates a Texture2DGroupIterator instance with all base material resources.

Returns returns the iterator instance.

PCompositeMaterialsIterator **GetCompositeMaterials ()**
creates a CompositeMaterialsIterator instance with all CompositeMaterials resources.

Returns returns the iterator instance.

PMultiPropertyGroupIterator **GetMultiPropertyGroups ()**
creates a MultiPropertyGroupsIterator instance with all MultiPropertyGroup resources.

Returns returns the iterator instance.

PSliceStackIterator **GetSliceStacks ()**
creates a resource iterator instance with all slice stack resources.

Returns returns the iterator instance.

PModel **MergeToModel ()**
Merges all components and objects which are referenced by a build item into a mesh. The memory is duplicated and a new model is created.

Returns returns the merged model instance

PMeshObject **AddMeshObject ()**
adds an empty mesh object to the model.

Returns returns the mesh object instance

PComponentsObject **AddComponentsObject ()**
adds an empty component object to the model.

Returns returns the components object instance

PSliceStack **AddSliceStack (const Lib3MF_double dZBottom)**
creates a new model slicestack by its id

Parameters **dZBottom** – Bottom Z value of the slicestack

Returns returns the new slicestack instance

PTexture2D **AddTexture2DFromAttachment (CAttachment *pTextureAttachment)**
adds a texture2d resource to the model. Its path is given by that of an existing attachment.

Parameters **pTextureAttachment** – attachment containing the image data.

Returns returns the new texture instance.

PBaseMaterialGroup **AddBaseMaterialGroup ()**
adds an empty BaseMaterialGroup resource to the model.

Returns returns the new base material instance.

PColorGroup **AddColorGroup** ()

adds an empty ColorGroup resource to the model.

Returns returns the new ColorGroup instance.

PTexture2DGroup **AddTexture2DGroup** (*CTexture2D* **pTexture2DInstance*)

adds an empty Texture2DGroup resource to the model.

Parameters **pTexture2DInstance** – The texture2D instance of the created Texture2DGroup.

Returns returns the new Texture2DGroup instance.

PCompositeMaterials **AddCompositeMaterials** (*CBaseMaterialGroup* **pBaseMaterialGroupInstance*)

adds an empty CompositeMaterials resource to the model.

Parameters **pBaseMaterialGroupInstance** – The BaseMaterialGroup instance of the created CompositeMaterials.

Returns returns the new CompositeMaterials instance.

PMultiPropertyGroup **AddMultiPropertyGroup** ()

adds an empty MultiPropertyGroup resource to the model.

Returns returns the new MultiPropertyGroup instance.

PBuildItem **AddBuildItem** (*CObject* **pObject*, **const** *sTransform* &*Transform*)

adds a build item to the model.

Parameters

- **pObject** – Object instance.
- **Transform** – Transformation matrix.

Returns returns the build item instance.

void RemoveBuildItem (*CBuildItem* **pBuildItemInstance*)

removes a build item from the model

Parameters **pBuildItemInstance** – Build item to remove.

PMetaDataGroup **GetMetaDataGroup** ()

Returns the metadata of the model as MetaDataGroup

Returns returns an Instance of the metadatagroup of the model

PAttachment **AddAttachment** (**const** std::string &*sURI*, **const** std::string &*sRelationshipType*)

adds an attachment stream to the model. The OPC part will be related to the model stream with a certain relationship type.

Parameters

- **sURI** – Path of the attachment
- **sRelationshipType** – Relationship type of the attachment

Returns Instance of the attachment object

void RemoveAttachment (*CAttachment* **pAttachmentInstance*)

Removes attachment from the model.

Parameters **pAttachmentInstance** – Attachment instance to remove

PAttachment **GetAttachment** (**const Lib3MF_uint32 nIndex**)

retrieves an attachment stream object from the model..

Parameters **nIndex** – Index of the attachment stream

Returns Instance of the attachment object

PAttachment **FindAttachment** (**const std::string &sURI**)

retrieves an attachment stream object from the model.

Parameters **sURI** – Path URI in the package

Returns Instance of the attachment object

Lib3MF_uint32 **GetAttachmentCount** ()

retrieves the number of attachments of the model.

Returns Returns the number of attachments.

bool HasPackageThumbnailAttachment ()

Retrieve whether the OPC package contains a package thumbnail.

Returns returns whether the OPC package contains a package thumbnail

PAttachment **CreatePackageThumbnailAttachment** ()

Create a new or the existing package thumbnail for the OPC package.

Returns Instance of a new or the existing thumbnailattachment object.

PAttachment **GetPackageThumbnailAttachment** ()

Get the attachment to the OPC package containing the package thumbnail.

Returns Instance of the thumbnailattachment object or NULL.

void RemovePackageThumbnailAttachment ()

Remove the attachment to the OPC package containing the package thumbnail.

void AddCustomContentType (**const std::string &sExtension, const std::string &sContentType**)

Adds a new Content Type to the model.

Parameters

- **sExtension** – File Extension
- **sContentType** – Content Type Identifier

void RemoveCustomContentType (**const std::string &sExtension**)

Removes a custom Content Type from the model (UTF8 version).

Parameters **sExtension** – File Extension

void SetRandomNumberCallback (**const RandomNumberCallback pTheCallback, const**

Lib3MF_pvoid pUserData)

Sets the random number generator callback for use in the library

Parameters

- **pTheCallback** – The callback used to generate random numbers
- **pUserData** – Userdata to be passed to the callback function

PKeyStore **GetKeyStore** ()

Gets the keystore associated with this model

Returns The package keystore

typedef std::shared_ptr<*CModel*> **Lib3MF::PModel**

Shared pointer to CModel to easily allow reference counting.

CMultiPropertyGroup

```
class Lib3MF::CMultiPropertyGroup : public CResource
```

Lib3MF_uint32 GetCount ()

Retrieves the count of MultiProperty-s in the MultiPropertyGroup.

Returns returns the count of MultiProperty-s

void GetAllPropertyIDs (std::vector<*Lib3MF_uint32*> &PropertyIDsBuffer)

returns all the PropertyIDs of all MultiProperty-s in this MultiPropertyGroup

Parameters **PropertyIDsBuffer** – PropertyID of the MultiProperty-s in the MultiPropertyGroup.

*Lib3MF_uint32 AddMultiProperty (const CInputVector<*Lib3MF_uint32*> &PropertyIDsBuffer)*

Adds a new MultiProperty to the MultiPropertyGroup.

Parameters **PropertyIDsBuffer** – The PropertyIDs of the new MultiProperty.

Returns returns the PropertyID of the new MultiProperty in the MultiPropertyGroup.

void SetMultiProperty (const *Lib3MF_uint32* nPropertyID, const CInputVec-

tor<*Lib3MF_uint32*> &PropertyIDsBuffer)

Sets the PropertyIDs of a MultiProperty.

Parameters

- **nPropertyID** – the PropertyID of the MultiProperty to be changed.
- **PropertyIDsBuffer** – The new PropertyIDs of the MultiProperty

void GetMultiProperty (const *Lib3MF_uint32* nPropertyID, std::vector<*Lib3MF_uint32*>

&PropertyIDsBuffer)

Obtains the PropertyIDs of a MultiProperty.

Parameters

- **nPropertyID** – the PropertyID of the MultiProperty to be queried.
- **PropertyIDsBuffer** – The PropertyIDs of the MultiProperty

void RemoveMultiProperty (const *Lib3MF_uint32* nPropertyID)

Removes a MultiProperty from this MultiPropertyGroup.

Parameters **nPropertyID** – the PropertyID of the MultiProperty to be removed.

Lib3MF_uint32 GetLayerCount ()

Retrieves the number of layers of this MultiPropertyGroup.

Returns returns the number of layers

Lib3MF_uint32 AddLayer (const sMultiPropertyLayer &TheLayer)

Adds a MultiPropertyLayer to this MultiPropertyGroup.

Parameters **TheLayer** – The MultiPropertyLayer to add to this MultiPropertyGroup

Returns returns the index of this MultiPropertyLayer

*sMultiPropertyLayer GetLayer (const *Lib3MF_uint32* nLayerIndex)*

Obtains a MultiPropertyLayer of this MultiPropertyGroup.

Parameters **nLayerIndex** – The Index of the MultiPropertyLayer queried

Returns The MultiPropertyLayer with index LayerIndex within MultiPropertyGroup

```
void RemoveLayer (const Lib3MF_uint32 nLayerIndex)
    Removes a MultiPropertyLayer from this MultiPropertyGroup.
```

Parameters **nLayerIndex** – The Index of the MultiPropertyLayer to be removed

```
typedef std::shared_ptr<CMultiPropertyGroup> Lib3MF::PMultiPropertyGroup
    Shared pointer to CMultiPropertyGroup to easily allow reference counting.
```

CMultiPropertyGroupIterator

```
class Lib3MF::CMultiPropertyGroupIterator : public CResourceIterator
```

```
PMultiPropertyGroup GetCurrentMultiPropertyGroup()
```

Returns the MultiPropertyGroup the iterator points at.

Returns returns the MultiPropertyGroup instance.

```
typedef std::shared_ptr<CMultiPropertyGroupIterator> Lib3MF::PMultiPropertyGroupIterator
    Shared pointer to CMultiPropertyGroupIterator to easily allow reference counting.
```

CObject

```
class Lib3MF::CObject : public CResource
```

```
eObjectType GetType()
```

Retrieves an object's type

Returns returns object type enum.

```
void SetType (const eObjectType eObjectType)
```

Sets an object's type

Parameters **eObjectType** – object type enum.

```
std::string GetName()
```

Retrieves an object's name

Returns returns object name.

```
void SetName (const std::string &sName)
```

Sets an object's name string

Parameters **sName** – new object name.

```
std::string GetPartNumber()
```

Retrieves an object's part number

Returns returns object part number.

```
void SetPartNumber (const std::string &sPartNumber)
```

Sets an objects partnumber string

Parameters **sPartNumber** – new object part number.

```
bool IsMeshObject()
```

Retrieves, if an object is a mesh object

Returns returns, whether the object is a mesh object

```
bool IsComponentsObject()
```

Retrieves, if an object is a components object

Returns returns, whether the object is a components object

bool IsValid()

Retrieves, if the object is valid according to the core spec. For mesh objects, we distinguish between the type attribute of the object:In case of object type other, this always means false.In case of object type model or solidsupport, this means, if the mesh suffices all requirements of the core spec chapter 4.1.In case of object type support or surface, this always means true.A component objects is valid if and only if it contains at least one component and all child components are valid objects.

Returns returns whether the object is a valid object description

void SetAttachmentAsThumbnail (*CAttachment* **pAttachment*)

Use an existing attachment as thumbnail for this object

Parameters *pAttachment* – Instance of a new or the existing thumbnailattachment object.

PAttachment GetThumbnailAttachment()

Get the attachment containing the object thumbnail.

Returns Instance of the thumbnailattachment object or NULL.

void ClearThumbnailAttachment()

Clears the attachment. The attachment instance is not removed from the package.

sBox GetOutbox()

Returns the outbox of a build item

Returns Outbox of this build item

std::string GetUUID (bool &*bHasUUID*)

Retrieves an object's uid string (see production extension specification)

Parameters *bHasUUID* – flag whether the build item has a UUID

Returns returns object uuid.

void SetUUID (const** std::string &*sUUID*)**

Sets a build object's uid string (see production extension specification)

Parameters *sUUID* – new object uid string.

PMetaDataGroup GetMetaDataGroup()

Returns the metadatagroup of this object

Returns returns an Instance of the metadatagroup of this object

void SetSlicesMeshResolution (const** *eSlicesMeshResolution* *eMeshResolution*)**

set the meshresolution of the mesh object

Parameters *eMeshResolution* – meshresolution of this object

eSlicesMeshResolution GetSlicesMeshResolution()

get the meshresolution of the mesh object

Returns meshresolution of this object

bool HasSlices (const** bool *bRecursive*)**

returns whether the Object has a slice stack. If Recursive is true, also checks whether any references object has a slice stack

Parameters *bRecursive* – check also all referenced objects?

Returns does the object have a slice stack?

void ClearSliceStack()

unlink the attached slicestack from this object. If no slice stack is attached, do noting.

PSliceStack **GetSliceStack** ()

get the Slicestack attached to the object

Returns returns the slicestack instance

void AssignSliceStack (*CSliceStack* **pSliceStackInstance*)

assigns a slicestack to the object

Parameters *pSliceStackInstance* – the new slice stack of this Object

typedef std::shared_ptr<*CObject*> **Lib3MF::PObj**

Shared pointer to CObject to easily allow reference counting.

CObjectIterator

class Lib3MF::CObjectIterator : public *CResourceIterator*

PObject **GetCurrentObject** ()

Returns the Object the iterator points at.

Returns returns the Object instance.

typedef std::shared_ptr<*CObjectIterator*> **Lib3MF::PObjIterator**

Shared pointer to CObjectIterator to easily allow reference counting.

CPackagePart

class Lib3MF::CPackagePart : public *CBase*

std::string **GetPath** ()

Returns the absolute path of this PackagePart.

Returns Returns the absolute path of this PackagePart

void SetPath (*const std::string &sPath*)

Sets the absolute path of this PackagePart.

Parameters *sPath* – Sets the absolute path of this PackagePart.

typedef std::shared_ptr<*CPackagePart*> **Lib3MF::PPackagePart**

Shared pointer to CPackagePart to easily allow reference counting.

CReader

class Lib3MF::CReader : public *CBase*

void ReadFromFile (*const std::string &sFilename*)

Reads a model from a file. The file type is specified by the Model Reader class

Parameters *sFilename* – Filename to read from

void ReadFromBuffer (*const CInputVector<Lib3MF_uint8> &BufferBuffer*)

Reads a model from a memory buffer.

Parameters *BufferBuffer* – Buffer to read from

```
void ReadFromCallback (const ReadCallback pTheReadCallback, const Lib3MF_uint64  

                     nStreamSize, const SeekCallback pTheSeekCallback, const  

                     Lib3MF_pvoid pUserData)
```

Reads a model and from the data provided by a callback function

Parameters

- **pTheReadCallback** – Callback to call for reading a data chunk
- **nStreamSize** – number of bytes the callback returns
- **pTheSeekCallback** – Callback to call for seeking in the stream.
- **pUserData** – Userdata that is passed to the callback function

```
void SetProgressCallback (const ProgressCallback pProgressCallback, const Lib3MF_pvoid  

                        pUserData)
```

Set the progress callback for calls to this writer

Parameters

- **pProgressCallback** – pointer to the callback function.
- **pUserData** – pointer to arbitrary user data that is passed without modification to the callback.

```
void AddRelationToRead (const std::string &sRelationshipType)
```

Adds a relationship type which shall be read as attachment in memory while loading

Parameters **sRelationshipType** – String of the relationship type

```
void RemoveRelationToRead (const std::string &sRelationshipType)
```

Removes a relationship type which shall be read as attachment in memory while loading

Parameters **sRelationshipType** – String of the relationship type

```
void SetStrictModeActive (const bool bStrictModeActive)
```

Activates (deactivates) the strict mode of the reader.

Parameters **bStrictModeActive** – flag whether strict mode is active or not.

```
bool GetStrictModeActive ()
```

Queries whether the strict mode of the reader is active or not

Returns returns flag whether strict mode is active or not.

```
std::string GetWarning (const Lib3MF_uint32 nIndex, Lib3MF_uint32 &nErrorCode)
```

Returns Warning and Error Information of the read process

Parameters

- **nIndex** – Index of the Warning. Valid values are 0 to WarningCount - 1
- **nErrorCode** – filled with the error code of the warning

Returns the message of the warning

```
Lib3MF_uint32 GetWarningCount ()
```

Returns Warning and Error Count of the read process

Returns filled with the count of the occurred warnings.

```
void AddKeyWrappingCallback (const std::string &sConsumerID, const KeyWrappingCallback  

                           pTheCallback, const Lib3MF_pvoid pUserData)
```

Registers a callback to deal with key wrapping mechanism from keystore

Parameters

- **sConsumerID** – The ConsumerID to register for
- **pTheCallback** – The callback used to decrypt data key
- **pUserData** – Userdata that is passed to the callback function

```
void SetContentEncryptionCallback(const ContentEncryptionCallback pTheCallback,  
                                  const Lib3MF_pvoid pUserData)
```

Registers a callback to deal with encryption of content

Parameters

- **pTheCallback** – The callback used to encrypt content
- **pUserData** – Userdata that is passed to the callback function

```
typedef std::shared_ptr<CReader> Lib3MF::PReader
```

Shared pointer to CReader to easily allow reference counting.

CResource

```
class Lib3MF::CResource : public CBase
```

```
Lib3MF_uint32 GetResourceID()
```

Retrieves the unique id of this resource within a package. This function will be removed in a later release in favor of GetUniqueResourceID

Returns Retrieves the unique id of this resource within a package.

```
Lib3MF_uint32 GetUniqueResourceID()
```

Retrieves the unique id of this resource within a package.

Returns Retrieves the unique id of this resource within a package.

```
PPackagePart PackagePart()
```

Returns the PackagePart within which this resource resides

Returns the PackagePart within which this resource resides.

```
void SetPackagePart(CPackagePart *pPackagePart)
```

Sets the new PackagePart within which this resource resides

Parameters **pPackagePart** – the new PackagePart within which this resource resides.

```
Lib3MF_uint32 GetModelResourceID()
```

Retrieves the id of this resource within a model.

Returns Retrieves the id of this resource within a model.

```
typedef std::shared_ptr<CResource> Lib3MF::PResource
```

Shared pointer to CResource to easily allow reference counting.

CResourceData

```
class Lib3MF::CResourceData : public CBase

PPackagePart GetPath()
Gets the encrypted part path

Returns The part path

eEncryptionAlgorithm GetEncryptionAlgorithm()
Gets the encryption algorithm used to encrypt this ResourceData

Returns The encryption algorithm

eCompression GetCompression()
Tells whether this ResourceData is compressed or not

Returns The compression method

void GetAdditionalAuthenticationData (std::vector<Lib3MF_uint8> &ByteDataBuffer)
Tells whether this ResourceData is compressed or not

Parameters ByteDataBuffer – The compression method

typedef std::shared_ptr<CResourceData> Lib3MF::PResourceData
Shared pointer to CResourceData to easily allow reference counting.
```

CResourceDataGroup

```
class Lib3MF::CResourceDataGroup : public CBase

std::string GetKeyUUID()
Sets the resourcedatagroup keyuuid

Returns The new resourcedatagroup keyuuid.

PAccesRight AddAccessRight (CConsumer *pConsumer, const eWrappingAlgorithm eWrappingAlgorithm, const eMgfAlgorithm eMgfAlgorithm, const eDigestMethod eDigestMethod)
Add accessright to resourcedatagroup element

Parameters

- pConsumer – The Consumer reference
- eWrappingAlgorithm – The key wrapping algorithm to be used
- eMgfAlgorithm – The mask generation function to be used
- eDigestMethod – The digest mechanism to be used

Returns The acess right instance

PAccesRight FindAccessRightByConsumer (CConsumer *pConsumer)
Finds the AccessRight associated with a Consumer

Parameters pConsumer – The Consumer instance

Returns The AcessRight instance

void RemoveAccessRight (CConsumer *pConsumer)
Removes access from a Consumer on this resource data group
```

Parameters `pConsumer` – The Consumer instance

typedef std::shared_ptr<*CResourceDataGroup*> **Lib3MF::PResourceDataGroup**
Shared pointer to CResourceDataGroup to easily allow reference counting.

CResourcelerator

class Lib3MF::CResourceIterator : public *CBase*

bool **MoveNext** ()

Iterates to the next resource in the list.

Returns Iterates to the next resource in the list.

bool **MovePrevious** ()

Iterates to the previous resource in the list.

Returns Iterates to the previous resource in the list.

PResource **GetCurrent** ()

Returns the resource the iterator points at.

Returns returns the resource instance.

PResourceIterator **Clone** ()

Creates a new resource iterator with the same resource list.

Returns returns the cloned Iterator instance

Lib3MF_uint64 **Count** ()

Returns the number of resources the iterator captures.

Returns returns the number of resources the iterator captures.

typedef std::shared_ptr<*CResourceIterator*> **Lib3MF::PResourceIterator**

Shared pointer to CResourceIterator to easily allow reference counting.

CSlice

class Lib3MF::CSlice : public *CBase*

void **SetVertices** (**const** *CInputVector*<*sPosition2D*> &*VerticesBuffer*)

Set all vertices of a slice. All polygons will be cleared.

Parameters `VerticesBuffer` – contains the positions.

void **GetVertices** (**std::vector**<*sPosition2D*> &*VerticesBuffer*)

Get all vertices of a slice

Parameters `VerticesBuffer` – contains the positions.

Lib3MF_uint64 **GetVertexCount** ()

Get the number of vertices in a slice

Returns the number of vertices in the slice

Lib3MF_uint64 **AddPolygon** (**const** *CInputVector*<*Lib3MF_uint32*> &*IndicesBuffer*)

Add a new polygon to this slice

Parameters `IndicesBuffer` – the new indices of the new polygon

Returns the index of the new polygon

Lib3MF_uint64 GetPolygonCount ()

Get the number of polygons in the slice

Returns the number of polygons in the slice

void SetPolygonIndices (const Lib3MF_uint64 nIndex, const CInputVector<Lib3MF_uint32>& IndicesBuffer)

Set all indices of a polygon

Parameters

- **nIndex** – the index of the polygon to manipulate
- **IndicesBuffer** – the new indices of the index-th polygon

void GetPolygonIndices (const Lib3MF_uint64 nIndex, std::vector<Lib3MF_uint32> &IndicesBuffer)

Get all vertices of a slice

Parameters

- **nIndex** – the index of the polygon to manipulate
- **IndicesBuffer** – the indices of the index-th polygon

Lib3MF_uint64 GetPolygonIndexCount (const Lib3MF_uint64 nIndex)

Get the number of vertices in a slice

Parameters **nIndex** – the index of the polygon to manipulate

Returns the number of indices of the index-th polygon

Lib3MF_double GetZTop ()

Get the upper Z-Coordinate of this slice.

Returns the upper Z-Coordinate of this slice

typedef std::shared_ptr<*CSlice*> **Lib3MF::PSlice**

Shared pointer to CSlice to easily allow reference counting.

CSliceStack

class *Lib3MF::CSliceStack* : **public** *CResource*

Lib3MF_double GetBottomZ ()

Get the lower Z-Coordinate of the slice stack.

Returns the lower Z-Coordinate the slice stack

Lib3MF_uint64 GetSliceCount ()

Returns the number of slices

Returns the number of slices

PSlice GetSlice (const Lib3MF_uint64 nSliceIndex)

Query a slice from the slice stack

Parameters **nSliceIndex** – the index of the slice

Returns the Slice instance

PSlice AddSlice (const Lib3MF_double dZTop)

Returns the number of slices

Parameters **dZTop** – upper Z coordinate of the slice

Returns a new Slice instance

Lib3MF_uint64 GetSliceRefCount ()

Returns the number of slice refs

Returns the number of slicereferences

void AddSliceStackReference (CSliceStack *pTheSliceStack)

Adds another existing slicestack as sliceref in this slicestack

Parameters **pTheSliceStack** – the slicestack to use as sliceref

PSliceStack GetSliceStackReference (const Lib3MF_uint64 nSliceRefIndex)

Adds another existing slicestack as sliceref in this slicestack

Parameters **nSliceRefIndex** – the index of the slice ref

Returns the slicestack that is used as sliceref

void CollapseSliceReferences ()

Removes the indirection of slices via slice-refs, i.e. creates the slices of all slice refs of this SliceStack as actual slices of this SliceStack. All previously existing slices or slicerefs will be removed.

void SetOwnPath (const std::string &sPath)

Sets the package path where this Slice should be stored. Input an empty string to reset the path

Parameters **sPath** – the package path where this Slice should be stored

std::string GetOwnPath ()

Obtains the package path where this Slice should be stored. Returns an empty string if the slicestack is stored within the root model.

Returns the package path where this Slice will be stored

typedef std::shared_ptr<CSliceStack> Lib3MF::PSliceStack

Shared pointer to CSliceStack to easily allow reference counting.

CSliceStackIterator

class Lib3MF::CSliceStackIterator : public CResourceIterator

PSliceStack GetCurrentSliceStack ()

Returns the SliceStack the iterator points at.

Returns returns the SliceStack instance.

typedef std::shared_ptr<CSliceStackIterator> Lib3MF::PSliceStackIterator

Shared pointer to CSliceStackIterator to easily allow reference counting.

CTexture2D

```
class Lib3MF::CTexture2D : public CResource
```

PAttachment **GetAttachment** ()

Retrieves the attachment located at the path of the texture.

Returns attachment that holds the texture's image information.

void SetAttachment (CAttachment *pAttachment)

Sets the texture's package path to the path of the attachment.

Parameters **pAttachment** – attachment that holds the texture's image information.

eTextureType **GetContentType** ()

Retrieves a texture's content type.

Returns returns content type enum.

void SetContentType (const eTextureType eContentType)

Retrieves a texture's content type.

Parameters **eContentType** – new Content Type

void GetTileStyleUV (eTextureTileStyle &eTileStyleU, eTextureTileStyle &eTileStyleV)

Retrieves a texture's tilestyle type.

Parameters

- **eTileStyleU** – returns tilestyle type enum.

- **eTileStyleV** – returns tilestyle type enum.

void SetTileStyleUV (const eTextureTileStyle eTileStyleU, const eTextureTileStyle eTileStyleV)

Sets a texture's tilestyle type.

Parameters

- **eTileStyleU** – new tilestyle type enum.

- **eTileStyleV** – new tilestyle type enum.

eTextureFilter **GetFilter** ()

Retrieves a texture's filter type.

Returns returns filter type enum.

void SetFilter (const eTextureFilter eFilter)

Sets a texture's filter type.

Parameters **eFilter** – sets new filter type enum.

typedef std::shared_ptr<CTexture2D> Lib3MF::PTexture2D

Shared pointer to CTexture2D to easily allow reference counting.

CTexture2DGroup

`class Lib3MF::CTexture2DGroup : public CResource`

`Lib3MF_uint32 GetCount()`

Retrieves the count of tex2coords in the Texture2DGroup.

Returns returns the count of tex2coords.

`void GetAllPropertyIDs(std::vector<Lib3MF_uint32> &PropertyIDsBuffer)`

returns all the PropertyIDs of all tex2coords in this Texture2DGroup

Parameters `PropertyIDsBuffer` – PropertyID of the tex2coords in the Texture2DGroup.

`Lib3MF_uint32 AddTex2Coord(const sTex2Coord &UVCoordinate)`

Adds a new tex2coord to the Texture2DGroup

Parameters `UVCoordinate` – The u/v-coordinate within the texture, horizontally right/vertically up from the origin in the lower left of the texture.

Returns returns new PropertyID of the new tex2coord in the Texture2DGroup.

`sTex2Coord GetTex2Coord(const Lib3MF_uint32 nPropertyID)`

Obtains a tex2coord to the Texture2DGroup

Parameters `nPropertyID` – the PropertyID of the tex2coord in the Texture2DGroup.

Returns The u/v-coordinate within the texture, horizontally right/vertically up from the origin in the lower left of the texture.

`void RemoveTex2Coord(const Lib3MF_uint32 nPropertyID)`

Removes a tex2coords from the Texture2DGroup.

Parameters `nPropertyID` – PropertyID of the tex2coords in the Texture2DGroup.

`PTexture2D GetTexture2D()`

Obtains the texture2D instance of this group.

Returns the texture2D instance of this group.

`typedef std::shared_ptr<CTexture2DGroup> Lib3MF::PTexture2DGroup`

Shared pointer to CTexture2DGroup to easily allow reference counting.

CTexture2DGroupIterator

`class Lib3MF::CTexture2DGroupIterator : public CResourceIterator`

`PTexture2DGroup GetCurrentTexture2DGroup()`

Returns the Texture2DGroup the iterator points at.

Returns returns the Texture2DGroup instance.

`typedef std::shared_ptr<CTexture2DGroupIterator> Lib3MF::PTexture2DGroupIterator`

Shared pointer to CTexture2DGroupIterator to easily allow reference counting.

CTexture2DIterator

```
class Lib3MF::CTexture2DIterator : public CResourceIterator
```

PTexture2D GetCurrentTexture2D()

Returns the Texture2D the iterator points at.

Returns returns the Texture2D instance.

```
typedef std::shared_ptr<CTexture2DIterator> Lib3MF::PTexture2DIterator
```

Shared pointer to CTexture2DIterator to easily allow reference counting.

CWriter

```
class Lib3MF::CWriter : public CBase
```

void WriteToFile (const std::string &sFilename)

Writes out the model as file. The file type is specified by the Model Writer class.

Parameters **sFilename** – Filename to write into

Lib3MF_uint64 GetStreamSize()

Retrieves the size of the full 3MF file stream.

Returns the stream size

void WriteToBuffer (std::vector<Lib3MF_uint8> &BufferBuffer)

Writes out the 3MF file into a memory buffer

Parameters **BufferBuffer** – buffer to write into

**void WriteToCallback (const WriteCallback pTheWriteCallback, const SeekCallback pTheSeek-
Callback, const Lib3MF_pvoid pUserData)**

Writes out the model and passes the data to a provided callback function. The file type is specified by the Model Writer class.

Parameters

- **pTheWriteCallback** – Callback to call for writing a data chunk
- **pTheSeekCallback** – Callback to call for seeking in the stream
- **pUserData** – Userdata that is passed to the callback function

**void SetProgressCallback (const ProgressCallback pProgressCallback, const Lib3MF_pvoid
pUserData)**

Set the progress callback for calls to this writer

Parameters

- **pProgressCallback** – pointer to the callback function.
- **pUserData** – pointer to arbitrary user data that is passed without modification to the callback.

Lib3MF_uint32 GetDecimalPrecision()

Returns the number of digits after the decimal point to be written in each vertex coordinate-value.

Returns The number of digits to be written in each vertex coordinate-value after the decimal point.

```
void SetDecimalPrecision (const Lib3MF_uint32 nDecimalPrecision)
    Sets the number of digits after the decimal point to be written in each vertex coordinate-value.

    Parameters nDecimalPrecision – The number of digits to be written in each vertex
        coordinate-value after the decimal point.

void SetStrictModeActive (const bool bStrictModeActive)
    Activates (deactivates) the strict mode of the reader.

    Parameters bStrictModeActive – flag whether strict mode is active or not.

bool GetStrictModeActive ()
    Queries whether the strict mode of the reader is active or not

    Returns returns flag whether strict mode is active or not.

std::string GetWarning (const Lib3MF_uint32 nIndex, Lib3MF_uint32 &nErrorCode)
    Returns Warning and Error Information of the read process

    Parameters
        • nIndex – Index of the Warning. Valid values are 0 to WarningCount - 1
        • nErrorCode – filled with the error code of the warning

    Returns the message of the warning

Lib3MF_uint32 GetWarningCount ()
    Returns Warning and Error Count of the read process

    Returns filled with the count of the occurred warnings.

void AddKeyWrappingCallback (const std::string &sConsumerID, const KeyWrappingCallback
    pTheCallback, const Lib3MF_pvoid pUserData)
    Registers a callback to deal with data key encryption/decryption from keystore

    Parameters
        • sConsumerID – The ConsumerID to register for
        • pTheCallback – The callback to be called for wrapping and encryption key
        • pUserData – Userdata that is passed to the callback function

void SetContentEncryptionCallback (const ContentEncryptionCallback pTheCallback,
    const Lib3MF_pvoid pUserData)
    Registers a callback to deal with encryption of content

    Parameters
        • pTheCallback – The callback used to encrypt content
        • pUserData – Userdata that is passed to the callback function

typedef std::shared_ptr<CWriter> Lib3MF::PWriter
    Shared pointer to CWriter to easily allow reference counting.
```

1.2 C-language bindings

This space describes the usage of lib3mf in a C host application.

TODO

1.3 Python-language bindings

TODO

1.4 Pascal-language bindings

TODO

1.5 C#-language bindings

This space describes the usage of lib3mf in a C# host application.

TODO

1.6 Golang-language bindings

TODO

1.7 NodeJS-language bindings

TODO

**CHAPTER
TWO**

OBTAINING LIB3MF

Simply download the precompiled binary SDK <https://github.com/3MFConsortium/lib3mf/releases>.

**CHAPTER
THREE**

USING LIB3MF

Allthough the different language bindings are kept as similar as possible, the usage of lib3mf still depends your programming language. You are best-off starting with one of the examples distributed in the SDK (<https://github.com/3MFConsortium/lib3mf/releases>).

In addition, the home pages for each language binding give detailed instructions on how to use them.

**CHAPTER
FOUR**

META INFORMATION

source/license

Reporting Bugs

The 3MF Consortium

Specification of the 3MF format

CHAPTER

FIVE

INDICES AND TABLES

- genindex
- search

INDEX

C

ContentEncryptionCallback (*C++ type*), 15

E

eBeamLatticeBallMode (*C++ enum*), 10
eBeamLatticeBallMode::All (*C++ enumerator*), 10
eBeamLatticeBallMode::eBlendMethod (*C++ enum*), 11
eBeamLatticeBallMode::eBlendMethod::Mix (*C++ enumerator*), 11
eBeamLatticeBallMode::eBlendMethod::Multiply (*C++ enumerator*), 11
eBeamLatticeBallMode::eBlendMethod::NoBlendMethod (*C++ enumerator*), 11
eBeamLatticeBallMode::eCompression (*C++ enum*), 12
eBeamLatticeBallMode::eCompression::Deflate (*C++ enumerator*), 12
eBeamLatticeBallMode::eCompression::NoCompression (*C++ enumerator*), 12
eBeamLatticeBallMode::eDigestMethod (*C++ enum*), 12
eBeamLatticeBallMode::eDigestMethod::SHA1 (*C++ enumerator*), 12
eBeamLatticeBallMode::eDigestMethod::SHA256 (*C++ enumerator*), 12
eBeamLatticeBallMode::eEncryptionAlgorithm (*C++ enum*), 11
eBeamLatticeBallMode::eEncryptionAlgorithm::AES256_GCM (*C++ enumerator*), 11
eBeamLatticeBallMode::eMgfAlgorithm (*C++ enum*), 11
eBeamLatticeBallMode::eMgfAlgorithm::MGF1_SHA1 (*C++ enumerator*), 11
eBeamLatticeBallMode::eMgfAlgorithm::MGF1_SHA224 (*C++ enumerator*), 12
eBeamLatticeBallMode::eMgfAlgorithm::MGF1_SHA256 (*C++ enumerator*), 12
eBeamLatticeBallMode::eMgfAlgorithm::MGF1_SHA384 (*C++ enumerator*), 12

eBeamLatticeBallMode::eMgfAlgorithm::MGF1_SHA512 (*C++ enumerator*), 12
eBeamLatticeBallMode::eProgressIdentifier (*C++ enum*), 10
eBeamLatticeBallMode::eProgressIdentifier::CLEANUP (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::CREATEOP (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::DONE (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::EXTRACT (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::QUERYCAN (*C++ enumerator*), 10
eBeamLatticeBallMode::eProgressIdentifier::READBUI (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READCUS (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READMES (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READNONI (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READRES (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READROOT (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READSLIC (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READSTR (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::READTEXT (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::WRITEATT (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::WRITECOM (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::WRITEKEY (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::WRITEMOD (*C++ enumerator*), 11
eBeamLatticeBallMode::eProgressIdentifier::WRITENON (*C++ enumerator*), 11

eBeamLatticeBallMode::eProgressIdentifier::PRWBETENODES::TexCoord (C++ enumerator), 9
(C++ enumerator), 11 eSlicesMeshResolution (C++ enum), 9
eBeamLatticeBallMode::eProgressIdentifier::SLWRBESMENR005TMD05::Fullres (C++ enumerator), 9
(C++ enumerator), 11 eBeamLatticeBallMode::eProgressIdentifier::SLWRBESM0D0E0ntion::Lowres (C++ enumerator), 9
(C++ enumerator), 11 eBeamLatticeBallMode::eProgressIdentifier::TEWRBUEFLICES (C++ enum), 10
(C++ enumerator), 11 eBeamLatticeBallMode::eProgressIdentifier::TEWRBUEFRIANGLEsinear (C++ enumerator), 10
(C++ enumerator), 11 eBeamLatticeBallMode::eWrappingAlgorithm 10
(C++ enum), 11 eBeamLatticeBallMode::eWrappingAlgorithm::TERSAU0AEStyle::Clamp (C++ enumerator),
(C++ enumerator), 11 eBeamLatticeBallMode::Mixed (C++ enumerator), 10 eBeamLatticeBallMode::Mixed (C++ enumerator), 10
eBeamLatticeBallMode::None (C++ enumerator), 10 eBeamLatticeBallMode::Mixed (C++ enumerator), 10
eBeamLatticeCapMode (C++ enum), 10 eBeamLatticeCapMode (C++ enum), 10
eBeamLatticeCapMode::Butt (C++ enumerator), 10 eBeamLatticeCapMode (C++ enum), 10
eBeamLatticeCapMode::HemiSphere (C++ enumerator), 10 eBeamLatticeCapMode (C++ enum), 10
eBeamLatticeCapMode::Sphere (C++ enumerator), 10 eBeamLatticeCapMode (C++ enum), 10
eBeamLatticeClipMode (C++ enum), 10 eBeamLatticeClipMode (C++ enum), 10
eBeamLatticeClipMode::Inside (C++ enumerator), 10 eBeamLatticeClipMode (C++ enum), 10
eBeamLatticeClipMode::NoClipMode (C++ enumerator), 10 eBeamLatticeClipMode (C++ enum), 10
eBeamLatticeClipMode::Outside (C++ enumerator), 10 eBeamLatticeClipMode (C++ enum), 10
eModelUnit (C++ enum), 9 eModelUnit (C++ enum), 9
eModelUnit::CentiMeter (C++ enumerator), 9 eModelUnit (C++ enum), 9
eModelUnit::Foot (C++ enumerator), 9 eModelUnit (C++ enum), 9
eModelUnit::Inch (C++ enumerator), 9 eModelUnit (C++ enum), 9
eModelUnit::Meter (C++ enumerator), 9 eModelUnit (C++ enum), 9
eModelUnit::MicroMeter (C++ enumerator), 9 eModelUnit (C++ enum), 9
eModelUnit::MilliMeter (C++ enumerator), 9 eModelUnit (C++ enum), 9
eObjectType (C++ enum), 9 eObjectType (C++ enum), 9
eObjectType::Model (C++ enumerator), 10 eObjectType (C++ enum), 9
eObjectType::Other (C++ enumerator), 10 eObjectType (C++ enum), 9
eObjectType::SolidSupport (C++ enumerator), 10 eObjectType (C++ enum), 9
eObjectType::Support (C++ enumerator), 10 eObjectType (C++ enum), 9
e.PropertyType (C++ enum), 9 e.PropertyType (C++ enum), 9
e.PropertyType::BaseMaterial (C++ enumerator), 9 e.PropertyType (C++ enum), 9
e.PropertyType::Colors (C++ enumerator), 9 e.PropertyType (C++ enum), 9
e.PropertyType::Composite (C++ enumerator), 9 e.PropertyType (C++ enum), 9
e.PropertyType::Multi (C++ enumerator), 9 e.PropertyType (C++ enum), 9
e.PropertyType::No.PropertyType (C++ enumerator), 9 e.PropertyType (C++ enum), 9
e.TextureFilter::Auto (C++ enumerator), 10 e.TextureFilter::Auto (C++ enumerator), 10
e.TextureFilter::Nearest (C++ enumerator), 10 e.TextureFilter::Nearest (C++ enumerator), 10
e.TextureTileStyle (C++ enum), 10 e.TextureTileStyle (C++ enum), 10
e.TextureType (C++ enum), 10 e.TextureType (C++ enum), 10
e.TextureType::JPEG (C++ enumerator), 10 e.TextureType (C++ enum), 10
e.TextureType::PNG (C++ enumerator), 10 e.TextureType (C++ enum), 10
e.TextureType::Unknown (C++ enumerator), 10 e.TextureType (C++ enum), 10

K

KeyWrappingCallback (C++ type), 14

L

Lib3MF::CAccessRight (C++ class), 16
Lib3MF::CAccessRight::GetConsumer (C++ function), 16
Lib3MF::CAccessRight::GetDigestMethod (C++ function), 16
Lib3MF::CAccessRight::GetMgfAlgorithm (C++ function), 16
Lib3MF::CAccessRight::GetWrappingAlgorithm (C++ function), 16
Lib3MF::CAttachment (C++ class), 16
Lib3MF::CAttachment::GetPath (C++ function), 16
Lib3MF::CAttachment::GetRelationshipType (C++ function), 17
Lib3MF::CAttachment::GetStreamSize (C++ function), 17
Lib3MF::CAttachment::PackagePart (C++ function), 17
Lib3MF::CAttachment::ReadFromBuffer (C++ function), 17
Lib3MF::CAttachment::ReadFromFile (C++ function), 17
Lib3MF::CAttachment::SetPath (C++ function), 16

```

Lib3MF::CAttachment::SetRelationshipType      function), 20
(C++ function), 17
Lib3MF::CAttachment::WriteToBuffer (C++      Lib3MF::CBeamSet::SetBallReferences
function), 17                               (C++ function), 20
Lib3MF::CAttachment::WriteToFile   (C++      Lib3MF::CBeamSet::SetIdentifier   (C++
function), 17                               function), 20
Lib3MF::CBase (C++ class), 17
Lib3MF::CBaseMaterialGroup (C++ class), 17
Lib3MF::CBaseMaterialGroup::AddMaterial     Lib3MF::CBuildItem (C++ class), 21
(C++ function), 18                           Lib3MF::CBuildItem::GetMetaDataSet
Lib3MF::CBaseMaterialGroup:: GetAllPropertyIDs (C++ function), 21
(C++ function), 17                           Lib3MF::CBuildItem::GetObjectResource
Lib3MF::CBaseMaterialGroup::GetCount        (C++ function), 21
(C++ function), 17                           Lib3MF::CBuildItem::GetObjectResourceID
Lib3MF::CBaseMaterialGroup::GetDisplayColor (C++ function), 21
(C++ function), 18                           Lib3MF::CBuildItem::GetObjectTransform
Lib3MF::CBaseMaterialGroup::GetName         (C++ function), 21
(C++ function), 18                           Lib3MF::CBuildItem::GetOutbox (C++ func-
                                         tion), 21
Lib3MF::CBaseMaterialGroup::RemoveMaterial (C++ function), 18
                                         Lib3MF::CBuildItem::GetPartNumber (C++ 
                                         function), 21
                                         Lib3MF::CBuildItem::GetUUID (C++ function),
                                         21
                                         Lib3MF::CBuildItem::HasObjectTransform
                                         (C++ function), 21
                                         Lib3MF::CBuildItem::SetObjectTransform
                                         GetCurrentElementGroup
                                         Lib3MF::CBuildItem::SetPartNumber (C++ 
                                         function), 21
                                         Lib3MF::CBuildItem::SetUUID (C++ function),
                                         21
                                         Lib3MF::CBuildItemIterator (C++ class), 22
                                         Lib3MF::CBuildItemIterator::Clone (C++ 
                                         function), 22
                                         Lib3MF::CBuildItemIterator::Count (C++ 
                                         function), 22
                                         Lib3MF::CBuildItemIterator::GetCurrent
                                         (C++ function), 22
                                         Lib3MF::CBuildItemIterator::MoveNext
                                         (C++ function), 22
                                         Lib3MF::CBuildItemIterator::MovePrevious
                                         (C++ function), 22
                                         Lib3MF::CColourGroup (C++ class), 22
                                         Lib3MF::CColourGroup::AddColor (C++ func-
                                         tion), 22
                                         Lib3MF::CColourGroup:: GetAllPropertyIDs
                                         (C++ function), 22
                                         Lib3MF::CColourGroup::GetColor (C++ func-
                                         tion), 23
                                         Lib3MF::CColourGroup::GetCount (C++ func-
                                         tion), 22
                                         Lib3MF::CColourGroup::RemoveColor (C++ 
                                         function), 22
                                         Lib3MF::CColourGroup::SetColor (C++ func-
                                         tion), 22
                                         
```

tion), 22

Lib3MF::CColorGroupIterator (*C++ class*), 23

Lib3MF::CColorGroupIterator::GetCurrentContentEncryptionParams (*C++ function*), 23

Lib3MF::CComponent (*C++ class*), 23

Lib3MF::CComponent::GetObjectResource (*C++ function*), 23

Lib3MF::CComponent::GetObjectResourceID (*C++ function*), 23

Lib3MF::CComponent::GetTransform (*C++ function*), 23

Lib3MF::CComponent::GetUUID (*C++ function*), 23

Lib3MF::CComponent::HasTransform (*C++ function*), 23

Lib3MF::CComponent::SetTransform (*C++ function*), 24

Lib3MF::CComponent::SetUUID (*C++ function*), 23

Lib3MF::CComponentsObject (*C++ class*), 24

Lib3MF::CComponentsObject::AddComponent (*C++ function*), 24

Lib3MF::CComponentsObject::GetComponent (*C++ function*), 24

Lib3MF::CComponentsObject::GetComponentCount (*C++ function*), 24

Lib3MF::CComponentsObjectIterator (*C++ class*), 24

Lib3MF::CComponentsObjectIterator::GetConsumerCount (*C++ function*), 24

Lib3MF::CCompositeMaterials (*C++ class*), 25

Lib3MF::CCompositeMaterials::AddComposite (*C++ function*), 25

Lib3MF::CCompositeMaterials::GetAllPropertyIDs (*function*), 25

Lib3MF::CCompositeMaterials::GetBaseMaterialGroup (*C++ function*), 25

Lib3MF::CCompositeMaterials::GetComposite (*C++ function*), 25

Lib3MF::CCompositeMaterials::GetCount (*C++ function*), 25

Lib3MF::CCompositeMaterials::RemoveComposite (*C++ function*), 25

Lib3MF::CCompositeMaterialsIterator (*C++ class*), 25

Lib3MF::CCompositeMaterialsIterator::GetCurrentContentEncryptionParams (*C++ function*), 25

Lib3MF::CConsumer (*C++ class*), 26

Lib3MF::CConsumer::GetConsumerID (*C++ function*), 26

Lib3MF::CConsumer::GetKeyID (*C++ function*), 26

Lib3MF::CConsumer::GetKeyValue (*C++ function*), 26

Lib3MF::CContentEncryptionParams (*C++ class*), 26

Lib3MF::CContentEncryptionParams::GetAdditionalAuthData (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetAuthenticationData (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetDescriptor (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetEncryptionAlgorithm (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetInitializationVector (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetKey (*C++ function*), 26

Lib3MF::CContentEncryptionParams::GetKeyUUID (*C++ function*), 27

Lib3MF::CContentEncryptionParams::SetAuthenticationData (*C++ function*), 26

Lib3MF::CInputVector (*C++ class*), 15

Lib3MF::CInputVector::CInputVector (*C++ function*), 16

Lib3MF::CInputVector::CInputVector::data (*C++ function*), 16

Lib3MF::CInputVector::CInputVector::size (*C++ function*), 16

Lib3MF::CKeyStore (*C++ class*), 27

Lib3MF::CKeyStore::AddConsumer (*C++ function*), 27

Lib3MF::CKeyStore::AddResourceDataGroup (*C++ function*), 28

Lib3MF::CKeyStore::FindConsumer (*C++ function*), 27

Lib3MF::CKeyStore::FindResourceDataGroup (*C++ function*), 28

Lib3MF::CKeyStore::FindResourceDataGroupCount (*C++ function*), 28

Lib3MF::CKeyStore::GetConsumer (*C++ function*), 27

Lib3MF::CKeyStore::GetConsumerCount (*function*), 27

Lib3MF::CKeyStore::GetResourceData (*C++ function*), 28

Lib3MF::CKeyStore::GetResourceDataCount (*C++ function*), 28

Lib3MF::CKeyStore::GetResourceDataGroup (*C++ function*), 27

Lib3MF::CKeyStore::GetResourceDataGroupCount (*C++ function*), 27

Lib3MF::CKeyStore::GetUUID (*C++ function*), 28

Lib3MF::CKeyStore::RemoveConsumer (*C++ function*), 27

Lib3MF::CKeyStore::RemoveResourceData (<i>C++ function</i>), 28	Lib3MF::CMetaData::GetName (<i>C++ function</i>), 31
Lib3MF::CKeyStore::RemoveResourceDataGroup (<i>C++ function</i>), 28	Lib3MF::CMetaData::GetNameSpace (<i>C++ function</i>), 31
Lib3MF::CKeyStore::SetUUID (<i>C++ function</i>), 28	Lib3MF::CMetaData::GetType (<i>C++ function</i>), 32
Lib3MF::CMeshObject (<i>C++ class</i>), 29	Lib3MF::CMetaData::GetValue (<i>C++ function</i>), 32
Lib3MF::CMeshObject::AddTriangle (<i>C++ function</i>), 29	Lib3MF::CMetaData::SetMustPreserve (<i>C++ function</i>), 32
Lib3MF::CMeshObject::AddVertex (<i>C++ function</i>), 29	Lib3MF::CMetaData::SetName (<i>C++ function</i>), 31
Lib3MF::CMeshObject::BeamLattice (<i>C++ function</i>), 31	Lib3MF::CMetaData::SetNameSpace (<i>C++ function</i>), 31
Lib3MF::CMeshObject::ClearAllProperties (<i>C++ function</i>), 31	Lib3MF::CMetaData::SetType (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetAllTriangleProperties (<i>C++ function</i>), 30	Lib3MF::CMetaData::SetValue (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetObjectLevelProperty (<i>C++ function</i>), 30	Lib3MF::CMetaDataGroup (<i>C++ class</i>), 32
Lib3MF::CMeshObject::GetTriangle (<i>C++ function</i>), 29	Lib3MF::CMetaDataGroup::AddMetaData (<i>C++ function</i>), 33
Lib3MF::CMeshObject::GetTriangleCount (<i>C++ function</i>), 29	Lib3MF::CMetaDataGroup::GetMetaData (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetTriangleIndices (<i>C++ function</i>), 30	Lib3MF::CMetaDataGroup::GetMetaDataByKey (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetTriangleProperties (<i>C++ function</i>), 30	Lib3MF::CMetaDataGroup::GetMetaDataCount (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetVertex (<i>C++ function</i>), 29	Lib3MF::CMetaDataGroup::RemoveMetaData (<i>C++ function</i>), 33
Lib3MF::CMeshObject::GetVertexCount (<i>C++ function</i>), 29	Lib3MF::CMetaDataGroup::RemoveMetaDataByIndex (<i>C++ function</i>), 32
Lib3MF::CMeshObject::GetVertices (<i>C++ function</i>), 29	Lib3MF::CModel (<i>C++ class</i>), 33
Lib3MF::CMeshObject::IsManifoldAndOriented (<i>C++ function</i>), 31	Lib3MF::CModel::AddAttachment (<i>C++ function</i>), 37
Lib3MF::CMeshObject::SetAllTriangleProperties (<i>C++ function</i>), 30	Lib3MF::CModel::AddBaseMaterialGroup (<i>C++ function</i>), 36
Lib3MF::CMeshObject::SetGeometry (<i>C++ function</i>), 31	Lib3MF::CModel::AddBuildItem (<i>C++ function</i>), 37
Lib3MF::CMeshObject::SetObjectLevelProperty (<i>C++ function</i>), 30	Lib3MF::CModel::AddColorGroup (<i>C++ function</i>), 37
Lib3MF::CMeshObject::SetTriangle (<i>C++ function</i>), 29	Lib3MF::CModel::AddComponentsObject (<i>C++ function</i>), 36
Lib3MF::CMeshObject::SetTriangleProperties (<i>C++ function</i>), 30	Lib3MF::CModel::AddCompositeMaterials (<i>C++ function</i>), 37
Lib3MF::CMeshObject::SetVertex (<i>C++ function</i>), 29	Lib3MF::CModel::AddCustomContentType (<i>C++ function</i>), 38
Lib3MF::CMeshObjectIterator (<i>C++ class</i>), 31	Lib3MF::CModel::AddMeshObject (<i>C++ function</i>), 36
Lib3MF::CMeshObjectIterator::GetCurrentModel (<i>C++ function</i>), 31	Lib3MF::CModel::AddMultiPropertyGroup (<i>C++ function</i>), 37
Lib3MF::CMetaData (<i>C++ class</i>), 31	Lib3MF::CModel::AddSliceStack (<i>C++ function</i>), 36
Lib3MF::CMetaData::GetKey (<i>C++ function</i>), 31	Lib3MF::CModel::AddTexture2DFromAttachment (<i>C++ function</i>), 36
Lib3MF::CMetaData::GetMustPreserve (<i>C++ function</i>), 32	

Lib3MF::CModel::AddTexture2DGroup (*C++ function*), 37
Lib3MF::CModel::CreatePackageThumbnailAttachment (*C++ function*), 38
Lib3MF::CModel::FindAttachment (*C++ function*), 38
Lib3MF::CModel::FindOrCreatePackagePart (*C++ function*), 33
Lib3MF::CModel::GetAttachment (*C++ function*), 38
Lib3MF::CModel::GetAttachmentCount (*C++ function*), 38
Lib3MF::CModel::GetBaseMaterialGroupByID (*C++ function*), 34
Lib3MF::CModel::GetBaseMaterialGroups (*C++ function*), 36
Lib3MF::CModel::GetBuildItems (*C++ function*), 35
Lib3MF::CModel::GetBuildUUID (*C++ function*), 35
Lib3MF::CModel::GetColorGroupByID (*C++ function*), 35
Lib3MF::CModel::GetColorGroups (*C++ function*), 36
Lib3MF::CModel::GetComponentsObjectByID (*C++ function*), 35
Lib3MF::CModel::GetComponentsObjects (*C++ function*), 35
Lib3MF::CModel::GetCompositeMaterials (*C++ function*), 36
Lib3MF::CModel::GetCompositeMaterialsByIDib3MF::CModel::RootModelPart (*C++ function*), 34
Lib3MF::CModel::GetKeyStore (*C++ function*), 38
Lib3MF::CModel::GetLanguage (*C++ function*), 33
Lib3MF::CModel::GetMeshObjectByID (*C++ function*), 34
Lib3MF::CModel::GetMeshObjects (*C++ function*), 35
Lib3MF::CModel::GetMetaDataSet (*C++ function*), 37
Lib3MF::CModel::GetMultiPropertyGroupByIDib3MF::CMultiPropertyGroup::AddMultiProperty (*C++ function*), 34
Lib3MF::CModel::GetMultiPropertyGroups (*C++ function*), 36
Lib3MF::CModel::GetObjects (*C++ function*), 35
Lib3MF::CModel::GetOutbox (*C++ function*), 35
Lib3MF::CModel::GetPackageThumbnailAttachment (*C++ function*), 38
Lib3MF::CModel::GetPropertyTypeByID (*C++ function*), 34
Lib3MF::CModel::GetResources (*C++ function*), 35
Lib3MF::CModel::GetSliceStackByID (*C++ function*), 35
Lib3MF::CModel::GetSliceStacks (*C++ function*), 36
Lib3MF::CModel::GetTexture2DByID (*C++ function*), 34
Lib3MF::CModel::GetTexture2DGroupByID (*C++ function*), 34
Lib3MF::CModel::GetTexture2DGroups (*C++ function*), 36
Lib3MF::CModel::GetTexture2Ds (*C++ function*), 35
Lib3MF::CModel::GetUnit (*C++ function*), 33
Lib3MF::CModel::HasPackageThumbnailAttachment (*C++ function*), 38
Lib3MF::CModel::MergeToModel (*C++ function*), 36
Lib3MF::CModel::QueryReader (*C++ function*), 34
Lib3MF::CModel::QueryWriter (*C++ function*), 34
Lib3MF::CModel::RemoveAttachment (*C++ function*), 37
Lib3MF::CModel::RemoveBuildItem (*C++ function*), 37
Lib3MF::CModel::RemoveCustomContentType (*C++ function*), 38
Lib3MF::CModel::RemovePackageThumbnailAttachment (*C++ function*), 38
Lib3MF::CModel::SetBuildUUID (*C++ function*), 35
Lib3MF::CModel::SetLanguage (*C++ function*), 34
Lib3MF::CModel::SetRandomNumberCallback (*C++ function*), 38
Lib3MF::CModel::SetUnit (*C++ function*), 33
Lib3MF::CMultiPropertyGroup (*C++ class*), 39
Lib3MF::CMultiPropertyGroup::AddLayer (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::AddMultiProperty (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::GetAllPropertyIDs (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::GetCount (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::GetLayer (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::GetLayerCount (*C++ function*), 39
Lib3MF::CMultiPropertyGroup::GetMultiProperty (*C++ function*), 39

Lib3MF::CMultiPropertyGroup::RemoveLayerLib3MF::CPackagePart::SetPath (*C++ function*, 40)
 Lib3MF::CMultiPropertyGroup::RemoveMultiLayerLib3MF::CReader (*C++ class*, 42)
 Lib3MF::CMultiPropertyGroup::SetMultiProperty (*C++ function*, 43)
 Lib3MF::CMultiPropertyGroupIterator (*C++ class*, 40)
 Lib3MF::CMultiPropertyGroupIterator::GetCurrentObject (*C++ function*, 43)
 Lib3MF::COobject (*C++ class*, 40)
 Lib3MF::COobject::AssignSliceStack (*C++ function*, 42)
 Lib3MF::COobject::ClearSliceStack (*C++ function*, 41)
 Lib3MF::COobject::ClearThumbnailAttachmentLib3MF::CReader::ReadFromCallback (*C++ function*, 41)
 Lib3MF::COobject::GetMetaDataGroup (*C++ function*, 41)
 Lib3MF::COobject::GetName (*C++ function*, 40)
 Lib3MF::COobject::GetOutbox (*C++ function*, 41)
 Lib3MF::COobject::GetPartNumber (*C++ function*, 40)
 Lib3MF::COobject::GetSlicesMeshResolution (*C++ function*, 41)
 Lib3MF::COobject::GetSliceStack (*C++ function*, 41)
 Lib3MF::COobject::GetThumbnailAttachment (*C++ function*, 41)
 Lib3MF::COobject::GetType (*C++ function*, 40)
 Lib3MF::COobject::GetUUID (*C++ function*, 41)
 Lib3MF::COobject::HasSlices (*C++ function*, 41)
 Lib3MF::COobject::IsComponentsObject (*C++ function*, 40)
 Lib3MF::COobject::IsMeshObject (*C++ function*, 40)
 Lib3MF::COobject::IsValid (*C++ function*, 41)
 Lib3MF::COobject::SetAttachmentAsThumbnailLib3MF::CResourceData::GetAdditionalAuthentication (*C++ function*, 41)
 Lib3MF::COobject::SetName (*C++ function*, 40)
 Lib3MF::COobject::SetPartNumber (*C++ function*, 40)
 Lib3MF::COobject::SetSlicesMeshResolution (*C++ function*, 41)
 Lib3MF::COobject::SetType (*C++ function*, 40)
 Lib3MF::COobject::SetUUID (*C++ function*, 41)
 Lib3MF::COobjectIterator (*C++ class*, 42)
 Lib3MF::COobjectIterator::GetCurrentObject (*C++ function*, 42)
 Lib3MF::CPackagePart (*C++ class*, 42)
 Lib3MF::CPackagePart::GetPath (*C++ function*, 42)
 Lib3MF::CReader::AddKeyWrappingCallback
 Lib3MF::CReader::AddRelationToRead (*C++ function*, 43)
 Lib3MF::CReader::GetStrictModeActive
 Lib3MF::CReader::GetWarning (*C++ function*, 43)
 Lib3MF::CReader::GetWarningCount (*C++ function*, 43)
 Lib3MF::CReader::ReadFromBuffer (*C++ function*, 42)
 Lib3MF::CReader::ReadFromCallback (*C++ function*, 42)
 Lib3MF::CReader::ReadFromFile (*C++ function*, 42)
 Lib3MF::CReader::RemoveRelationToRead (*C++ function*, 43)
 Lib3MF::CReader::SetContentEncryptionCallback (*C++ function*, 44)
 Lib3MF::CReader::SetProgressCallback (*C++ function*, 43)
 Lib3MF::CReader::SetStrictModeActive (*C++ function*, 43)
 Lib3MF::CResource (*C++ class*, 44)
 Lib3MF::CResource::GetModelResourceID (*C++ function*, 44)
 Lib3MF::CResource::GetResourceID (*C++ function*, 44)
 Lib3MF::CResource::GetUniqueResourceID (*C++ function*, 44)
 Lib3MF::CResource::PackagePart (*C++ function*, 44)
 Lib3MF::CResource::SetPackagePart (*C++ function*, 44)
 Lib3MF::CResourceData (*C++ class*, 45)
 Lib3MF::CResourceData::GetAdditionalAuthentication (*C++ function*, 45)
 Lib3MF::CResourceData::GetCompression (*C++ function*, 45)
 Lib3MF::CResourceData::GetEncryptionAlgorithm (*C++ function*, 45)
 Lib3MF::CResourceData::GetPath (*C++ function*, 45)
 Lib3MF::CResourceDataGroup (*C++ class*, 45)
 Lib3MF::CResourceDataGroup::AddAccessRight
 Lib3MF::CResourceDataGroup::FindAccessRightByConsumer
 Lib3MF::CResourceDataGroup::GetKeyUUID (*C++ function*, 45)

Lib3MF::CResourceDataGroup::RemoveAccessRight (*C++ function*), 48
 (*C++ function*), 45
Lib3MF::CResourceIterator (*C++ class*), 46
Lib3MF::CResourceIterator::Clone (*C++ function*), 46
Lib3MF::CResourceIterator::Count (*C++ function*), 46
Lib3MF::CResourceIterator::GetCurrent (*C++ function*), 46
Lib3MF::CResourceIterator::MoveNext (*C++ function*), 46
Lib3MF::CResourceIterator::MovePrevious (*C++ function*), 46
Lib3MF::CSlice (*C++ class*), 46
Lib3MF::CSlice::AddPolygon (*C++ function*), 46
Lib3MF::CSlice::GetPolygonCount (*C++ function*), 47
Lib3MF::CSlice::GetPolygonIndexCount (*C++ function*), 47
Lib3MF::CSlice::GetPolygonIndices (*C++ function*), 47
Lib3MF::CSlice::GetVertexCount (*C++ function*), 46
Lib3MF::CSlice::GetVertices (*C++ function*), 46
Lib3MF::CSlice::GetZTop (*C++ function*), 47
Lib3MF::CSlice::SetPolygonIndices (*C++ function*), 47
Lib3MF::CSlice::SetVertices (*C++ function*), 46
Lib3MF::CSliceStack (*C++ class*), 47
Lib3MF::CSliceStack::AddSlice (*C++ function*), 47
Lib3MF::CSliceStack::AddSliceStackReference (*C++ function*), 48
Lib3MF::CSliceStack::CollapseSliceReferences
 (*C++ function*), 48
Lib3MF::CSliceStack::GetBottomZ (*C++ function*), 47
Lib3MF::CSliceStack::GetOwnPath (*C++ function*), 48
Lib3MF::CSliceStack::GetSlice (*C++ function*), 47
Lib3MF::CSliceStack::GetSliceCount (*C++ function*), 47
Lib3MF::CSliceStack::GetSliceRefCount
 (*C++ function*), 48
Lib3MF::CSliceStack::GetSliceStackReference
 (*C++ function*), 48
Lib3MF::CSliceStack::SetOwnPath (*C++ function*), 48
Lib3MF::CSliceStackIterator (*C++ class*), 48
Lib3MF::CSliceStackIterator::GetCurrentSliceState), 7
 (*C++ function*), 49
Lib3MF::CTexture2D (*C++ class*), 49
Lib3MF::CTexture2D::GetAttachment (*C++ function*), 49
Lib3MF::CTexture2D::GetContentType (*C++ function*), 49
Lib3MF::CTexture2D::GetFilter (*C++ function*), 49
Lib3MF::CTexture2D::GetTileStyleUV (*C++ function*), 49
Lib3MF::CTexture2D::SetAttachment (*C++ function*), 49
Lib3MF::CTexture2D::SetContentType (*C++ function*), 49
Lib3MF::CTexture2D::SetFilter (*C++ function*), 49
Lib3MF::CTexture2D::SetTileStyleUV (*C++ function*), 49
Lib3MF::CTexture2DGroup (*C++ class*), 50
Lib3MF::CTexture2DGroup::AddTex2Coord
 (*C++ function*), 50
Lib3MF::CTexture2DGroup:: GetAllPropertyIDs
 (*C++ function*), 50
Lib3MF::CTexture2DGroup::GetCount (*C++ function*), 50
Lib3MF::CTexture2DGroup::GetTex2Coord
 (*C++ function*), 50
Lib3MF::CTexture2DGroup::GetTexture2D
 (*C++ function*), 50
Lib3MF::CTexture2DGroup::RemoveTex2Coord
 (*C++ function*), 50
Lib3MF::CTexture2DGroupIterator (*C++ class*), 50
Lib3MF::CTexture2DGroupIterator::GetCurrentTexture2D
 (*C++ function*), 50
Lib3MF::CTexture2DIterator (*C++ class*), 51
Lib3MF::CTexture2DIterator::GetCurrentTexture2D
 (*C++ function*), 51
Lib3MF::CWrapper (*C++ class*), 6
Lib3MF::CWrapper::Acquire (*C++ function*), 6
Lib3MF::CWrapper::ColorToFloatRGBA (*C++ function*), 8
Lib3MF::CWrapper::ColorToRGBA (*C++ function*), 7
Lib3MF::CWrapper::CreateModel (*C++ function*), 6
Lib3MF::CWrapper::FloatRGBAToColor (*C++ function*), 7
Lib3MF::CWrapper::GetBuildInformation
 (*C++ function*), 6
Lib3MF::CWrapper::GetIdentityTransform
 (*C++ function*), 8
Lib3MF::CWrapper::GetLastError (*C++ function*), 7

Lib3MF::CWrapper::GetLibraryVersion (<i>C++ function</i>), 6	Lib3MF::PBaseMaterialGroup (<i>C++ type</i>), 18
Lib3MF::CWrapper::GetPrereleaseInformation (<i>C++ function</i>), 6	Lib3MF::PBaseMaterialGroupIterator (<i>C++ type</i>), 18
Lib3MF::CWrapper::GetScaleTransform (<i>C++ function</i>), 8	Lib3MF::PBeamLattice (<i>C++ type</i>), 19
Lib3MF::CWrapper::GetSpecificationVersion (<i>C++ function</i>), 6	Lib3MF::PBeamSet (<i>C++ type</i>), 20
Lib3MF::CWrapper::GetTranslationTransform (<i>C++ function</i>), 8	Lib3MF::PBuildItem (<i>C++ type</i>), 21
Lib3MF::CWrapper::GetUniformScaleTransform (<i>C++ function</i>), 8	Lib3MF::PBuildItemIterator (<i>C++ type</i>), 22
Lib3MF::CWrapper::Release (<i>C++ function</i>), 6	Lib3MF::PColourGroup (<i>C++ type</i>), 23
Lib3MF::CWrapper::RetrieveProgressMessage (<i>C++ function</i>), 7	Lib3MF::PColourGroupIterator (<i>C++ type</i>), 23
Lib3MF::CWrapper::RGBAToColor (<i>C++ func- tion</i>), 7	Lib3MF::PComponent (<i>C++ type</i>), 24
Lib3MF::CWrapper::SetJournal (<i>C++ func- tion</i>), 7	Lib3MF::PComponentsObject (<i>C++ type</i>), 24
Lib3MF::CWriter (<i>C++ class</i>), 51	Lib3MF::PComponentsObjectIterator (<i>C++ type</i>), 24
Lib3MF::CWriter::AddKeyWrappingCallback (<i>C++ function</i>), 52	Lib3MF::PCompositeMaterials (<i>C++ type</i>), 25
Lib3MF::CWriter::GetDecimalPrecision (<i>C++ function</i>), 51	Lib3MF::PCompositeMaterialsIterator (<i>C++ type</i>), 25
Lib3MF::CWriter::GetStreamSize (<i>C++ func- tion</i>), 51	Lib3MF::PConsumer (<i>C++ type</i>), 26
Lib3MF::CWriter::GetStrictModeActive (<i>C++ function</i>), 52	Lib3MF::PContentEncryptionParams (<i>C++ type</i>), 27
Lib3MF::CWriter::GetWarning (<i>C++ function</i>), 52	Lib3MF::PKeyStore (<i>C++ type</i>), 29
Lib3MF::CWriter::GetWarningCount (<i>C++ function</i>), 52	Lib3MF::PMeshObject (<i>C++ type</i>), 31
Lib3MF::CWriter::SetContentEncryptionCall- back (<i>C++ function</i>), 52	Lib3MF::PMeshObjectIterator (<i>C++ type</i>), 31
Lib3MF::CWriter::SetDecimalPrecision (<i>C++ function</i>), 52	Lib3MF::PMetaData (<i>C++ type</i>), 32
Lib3MF::CWriter::SetProgressCallback (<i>C++ function</i>), 51	Lib3MF::PMetaDataGroup (<i>C++ type</i>), 33
Lib3MF::CWriter::SetStrictModeActive (<i>C++ function</i>), 52	Lib3MF::PModel (<i>C++ type</i>), 38
Lib3MF::CWriter::WriteToBuffer (<i>C++ func- tion</i>), 51	Lib3MF::PMultiPropertyGroup (<i>C++ type</i>), 40
Lib3MF::CWriter::WriteToCallback (<i>C++ function</i>), 51	Lib3MF::PMultiPropertyGroupIterator (<i>C++ type</i>), 40
Lib3MF::CWriter::WriteToFile (<i>C++ function</i>), 51	Lib3MF::PObject (<i>C++ type</i>), 42
Lib3MF::ELib3MFException (<i>C++ class</i>), 15	Lib3MF::PObjectIterator (<i>C++ type</i>), 42
Lib3MF::ELib3MFException::ELib3MFException (<i>C++ function</i>), 15	Lib3MF::PPackagePart (<i>C++ type</i>), 42
Lib3MF::ELib3MFException::ELib3MFException (<i>C++ function</i>), 15	Lib3MF::PReader (<i>C++ type</i>), 44
Lib3MF::PAccessRight (<i>C++ type</i>), 16	Lib3MF::PResource (<i>C++ type</i>), 44
Lib3MF::PAttachment (<i>C++ type</i>), 17	Lib3MF::PResourceData (<i>C++ type</i>), 45
Lib3MF::PBase (<i>C++ type</i>), 17	Lib3MF::PResourceDataGroup (<i>C++ type</i>), 46
	Lib3MF::PResourceIterator (<i>C++ type</i>), 46
	Lib3MF::PSlice (<i>C++ type</i>), 47
	Lib3MF::PSliceStack (<i>C++ type</i>), 48
	Lib3MF::PSliceStackIterator (<i>C++ type</i>), 48
	Lib3MF::PTexture2D (<i>C++ type</i>), 49
	Lib3MF::PTexture2DGroup (<i>C++ type</i>), 50
	Lib3MF::PTexture2DGroupIterator (<i>C++ type</i>), 50
	Lib3MF::PTexture2DIterator (<i>C++ type</i>), 51
	Lib3MF::PWrapper (<i>C++ type</i>), 8
	Lib3MF::PWriter (<i>C++ type</i>), 52
	Lib3MF_double (<i>C++ type</i>), 9
	Lib3MF_int32 (<i>C++ type</i>), 9
	Lib3MF_int64 (<i>C++ type</i>), 9
	Lib3MF_int8 (<i>C++ type</i>), 9
	Lib3MF_pvoid (<i>C++ type</i>), 9
	Lib3MF_single (<i>C++ type</i>), 9
	Lib3MF_uint16 (<i>C++ type</i>), 9

Lib3MF_uint32 (*C++ type*), 9
Lib3MF_uint64 (*C++ type*), 9
Lib3MF_uint8 (*C++ type*), 9
Lib3MFResult (*C++ type*), 9

P

ProgressCallback (*C++ type*), 13

R

RandomNumberCallback (*C++ type*), 14
ReadCallback (*C++ type*), 14

S

sBall (*C++ struct*), 13
sBall::m_Index (*C++ member*), 13
sBall::m_Radius (*C++ member*), 13
sBeam (*C++ struct*), 13
sBeam::m_CapModes (*C++ member*), 13
sBeam::m_Indices (*C++ member*), 13
sBeam::m_Radii (*C++ member*), 13
sBox (*C++ struct*), 13
sBox::m_MaxCoordinate (*C++ member*), 13
sBox::m_MinCoordinate (*C++ member*), 13
sColor (*C++ struct*), 13
sColor::m_Alpha (*C++ member*), 13
sColor::m_Blue (*C++ member*), 13
sColor::m_Green (*C++ member*), 13
sColor::m_Red (*C++ member*), 13
sCompositeConstituent (*C++ struct*), 12
sCompositeConstituent::m_MixingRatio
 (*C++ member*), 12
sCompositeConstituent::m_PropertyID
 (*C++ member*), 12
SeekCallback (*C++ type*), 14
sMultiPropertyLayer (*C++ struct*), 12
sMultiPropertyLayer::m_ResourceID (*C++
member*), 12
sMultiPropertyLayer::m_TheBlendMethod
 (*C++ member*), 12
sPosition (*C++ struct*), 12
sPosition2D (*C++ struct*), 12
sPosition2D::m_Coordinates (*C++ member*),
 12
sPosition::m_Coordinates (*C++ member*), 12
sTex2Coord (*C++ struct*), 12
sTex2Coord::m_U (*C++ member*), 13
sTex2Coord::m_V (*C++ member*), 13
sTransform (*C++ struct*), 13
sTransform::m_Fields (*C++ member*), 13
sTriangle (*C++ struct*), 12
sTriangle::m_Indices (*C++ member*), 12
sTriangleProperties (*C++ struct*), 12
sTriangleProperties::m_PropertyIDs (*C++
member*), 12

sTriangleProperties::m_ResourceID (*C++
member*), 12

W

WriteCallback (*C++ type*), 13